

OMRON

形3G3JX-A□ 簡易型小型インバータ


取扱説明書

このたびは、SYSDRIVE 形 3G3JX シリーズをお買い求めいただきまして、誠にありがとうございます。
この製品を安全に正しくご使用いただくために、お使いになる前に、この取扱説明書と安全上のご注意および下記のマニュアルを熟読し、機器の知識、安全上の情報、注意事項のすべてについて習熟してからご使用ください。また、お読みになったあとも、いつも手元においてご使用ください。


マニュアル名称	マニュアル番号
3G3JX シリーズ ユーザーズマニュアル	SBCE-345

オムロン株式会社
©OMRON Corporation 2013 All Rights Reserved. 0193670-5C NT302E

各部の名称




取り付けと配線



形3G3JX-	W	W1	H	H1	D
A2002, AE002	80	67	155	143	95.5
A2004, AE004					109.5
A2007					132.5
A4004, AE007	110	98	189	176	130.5
A2015, A2022, A2037, A4007, A4015, A4022, A4037, AE015, AE022					157.5
A2055, A2075, A4055, A4075					167.5

[mm]



注1. 単相AC200V入力時は、L1, N/L3の2端子に接続してください。
注2. リレー出力の工場出荷時設定は、MAがb接点、MBがa接点です。

■端子記号、ねじサイズ、締め付けトルク

種類	端子記号	A2002 ~ A2007 AE002 ~ AE004	A2015 ~ A2037 A4004 ~ A4037 AE007 ~ AE022	A2055 ~ A2075 A4055 ~ A4075
主回路	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3 アース (記号)	M3.5 0.8N・m (max.0.9N・m)	M4 1.2N・m (max.1.3N・m)	M5 3.0N・m (max.3.3N・m)
オプション	N/-, P/+2, +1			
制御回路	AM, FS, FV, FI, FC, S5, S4, S3, S2, S1, SC, PSC, P24, PC, P1	M2 / 0.2N・m (max.0.25N・m)		
リレー	MA, MB, MC	M2.5 / 0.5N・m (max.0.6N・m)		
アース	-	M4	M5	

注. AE□□□は、R/L1がL1、S/L2がL2、T/L3がN/L3になります。

キーの説明

名称	内容
モードキー	<p>コマンド設定とデータ設定の状態切替、および、基本機能と拡張機能のモード切替に使用します。</p> <p>■状態遷移</p> <p>※モードキーを3秒以上押し続けると、d001にジャンプします。</p>
インクリメントキー	設定値やパラメータ、コマンドの変更を行います。
デクリメントキー	
RUN	RUN キー 運転を開始します。正転・逆転は、F004の設定に従います。
STOP/RESET	STOP/RESET キー 運転を停止します。異常発生時はリセットキーになります。
エンターキー	エンターキー データを確定し記憶します。

パラメータ No.	機能名称	モニタまたはデータ範囲
d001	出力周波数モニタ	0.0 ~ 400.0
d002	出力電流モニタ	0.0 ~ 999.9
d003	回転方向モニタ	F: 正転 / o: 停止 / r: 逆転
d004	PID フィードバック値モニタ	0.00 ~ 9999. (PID機能選択時有効)
d007	出力周波数モニタ (換算後)	0.00 ~ 9999. (出力周波数 × b086 の換算係数)
d013	出力電圧モニタ	0. ~ 600.
d016	出力電圧モニタ	0. ~ 9999.
d017	電源 ON 時間モニタ	0. ~ 9999.
d018	フィン温度モニタ	0.0 ~ 200.0
d080	異常回数モニタ	0. ~ 9999.
d081	異常モニタ 1 (最新)	エラーコード (発生時の状態) → 出力周波数 → 出力電流 → 内部直流電圧 → RUN 時間 → ON 時間
d082	異常モニタ 2	
d083	異常モニタ 3	
d102	直流電圧モニタ	0.0 ~ 999.9
d104	電子サーマルモニタ	0.0 ~ 100.0
F001	出力周波数設定 / モニタ	始動周波数 ~ 最高周波数
F002 / F202	加速時間 1 / 第 2 加速時間 2	0.01 ~ 3000.
F003 / F203	減速時間 1 / 第 2 減速時間 2	0.01 ~ 3000.
F004	オペレータ 回転方向選択	00: 正転 / 01: 逆転
A001 / A201	周波数指令選択 / 第 2 周波数指令選択	00: オペレータ (ボリウム) / 01: ターミナル / 02: オペレータ (F001) / 03: Modbus 通信 / 10: 周波数演算結果
A002 / A202	運転指令選択 / 第 2 運転指令選択	01: ターミナル / 02: オペレータ / 03: Modbus 通信
A003 / A203	基底周波数 / 第 2 基底周波数	30. ~ 最高周波数 [A004/A204]
A004 / A204	最高周波数 / 第 2 最高周波数	30. ~ 400.
A005	FV/FI 選択	02: AT 端子で FV/ ボリウムの切替 03: AT 端子で FI/ ボリウムの切替 04: FV 入力のみ / 05: FI 入力のみ
A020 / A220	多段速指令 0 / 第 2 多段速指令 0	0.0 / 始動周波数 ~ 最高周波数
A021 ~ A035	多段速指令 1 ~ 15	0.0 / 始動周波数 ~ 最高周波数
A038	ジョギング周波数	0.00 / 始動周波数 ~ 9.99
A039	ジョギング停止選択	00: 停止時フリーラン / 01: 停止時減速停止 / 02: 停止時直流制動
A045 / A245	出力電圧ゲイン / 第 2 出力電圧ゲイン	20. ~ 100.
A097	加速パターン選択	
A098	減速パターン選択	00: 直線 / 01: S 字カーブ
b001	リトライ選択	00: アラーム / 01: 0Hz スタート / 02: 周波数合わせスタート / 03: 周波数合わせ減速停止後トリップ
b002	瞬停許容時間	0.3 ~ 25.0
b083	キャリア周波数	2.0 ~ 12.0
b084	初期化選択	00: トリップ内容クリア 01: データの初期化 02: トリップ内容クリアとデータの初期化
b130	過電圧 LAD ストップ機能	00: 無効 / 01: 有効
b131	過電圧 LAD ストップ機能 レベル設定	200V 級 : 330. ~ 395. 400V 級 : 660. ~ 790.
C001 / C201	多機能入力 1 選択 / 第 2 多機能入力 1 選択	00: FW (正転) / 01: RV (逆転) / 02: CF1 (多段速設定バイナリ 1) / 03: CF2 (多段速設定バイナリ 2) / 04: CF3 (多段速設定バイナリ 3) / 05: CF4 (多段速設定バイナリ 4) / 06: JG (ジョギング) / 07: DB (外部直流制動) / 08: SET (第 2 制御) / 09: 2CH (2 段加速) / 11: FRS (フリーランストップ) / 12: EXT (外部トリップ) / 13: USP (USP 機能) / 15: SFT (ソフトロック) / 16: AT (アナログ入力切替) / 18: RS (リセット) / 19: PTC (サーミスタ入力) / 20: STA (3 ワイヤ機能) / 21: STP (3 ワイヤ停止) / 22: F/R (3 ワイヤ正逆) / 23: PID (PID 有効 / 無効) / 24: PIDC (PID 積分リセット) / 27: UP (UP/DWN 機能増速) / 28: DWN (UP/DWN 機能減速) / 29: UDC (UP/DWN 機能データクリア) / 31: OPE (強制オペレータ) / 50: ADD (周波数加算) / 51: F-TM (強制端子台) / 52: RDY (レディ機能) / 53: SP-SET (特殊第 2 機能) / 64: EMR (緊急遮断) / 255: 機能なし
C002 / C202	多機能入力 2 選択 / 第 2 多機能入力 2 選択	
C003 / C203	多機能入力 3 選択 / 第 2 多機能入力 3 選択	
C004 / C204	多機能入力 4 選択 / 第 2 多機能入力 4 選択	
C005 / C205	多機能入力 4 選択 / 第 2 多機能入力 4 選択	

パラメータ No.	機能名称	モニタまたはデータ範囲
C011 ~ C015	多機能入力 1 ~ 5 動作選択	00: N.O. 01: N.C.
C021	多機能出力端子 P1 選択	00: RUN (運転中信号) / 01: FA1 (定速到達時信号) / 02: FA2 (設定周波数以上到達信号) / 03: OL (過負荷予告) / 04: OD (PID 偏差過大) / 05: AL (アラーム出力) / 06: Dc (断線検出) / 07: FBV (PID FB 状態出力) / 08: NDC (ネットワークエラー) / 09: LOG (論理演算出力) / 10: ODc (通信オプション断線) / 43: LOC (軽負荷検出信号)
C026	リレー出力 (MA, MB) 機能選択	
C028	AM 選択	00: 出力周波数 / 01: 出力電流
C031	多機能出力端子 P1 接点選択	
C036	リレー出力 (MA, MB) 接点選択	00: MA が a 接点, MB が b 接点 01: MA が b 接点, MB が a 接点
H003 / H203	モータ容量選択 / 第 2 モータ容量選択	200V 級 : 0.2 ~ 7.5 400V 級 : 0.4 ~ 7.5
H004 / H204	モータ極数選択 / 第 2 モータ極数選択	2 / 4 / 6 / 8

安全上のご注意

■安全に使用していただくための表示と意味について

この取扱説明書では、インバータ形 3G3JX を安全にご使用いただくために注意事項を次のような表示と記号で示しています。ここで示した注意事項は、安全に関する重大な内容を記載しています。必ず守ってください。表示と記号は次のとおりです。

■警告表示の意味

危険 取り扱いを誤った場合に、危険な状況が起こりえて、死亡または重傷を受ける可能性が想定される場合、および深刻な物的損害の発生が想定される場合。

注意 取り扱いを誤った場合に、危険な状況が起こりえて、中程度の傷害や軽傷を受ける可能性が想定される場合および物的損害のみの発生が想定される場合。

■警告表示

危険

- 万 one の場合、感電による重度の傷害が起こるおそれがあります。入力電源 OFF を確認してから正しく配線してください。
- 万 one の場合、感電による重度の傷害が起こるおそれがあります。配線作業は、電気工事の専門家が行ってください。
- 万 one の場合、感電・発火による重度の傷害が起こるおそれがあります。接地端子は必ずアースしてください。(200V 級 : D 種接地, 400V 級 : C 種接地)
- 万 one の場合、感電による重度の傷害が起こるおそれがあります。通電中および電源遮断後 5 分以内はフロントカバーを外さないでください。
- 万 one の場合、感電による重度の傷害が起こるおそれがあります。濡れた手でオペレータ、スイッチ類を操作しないでください。
- 万 one の場合、感電による重度の傷害が起こるおそれがあります。緊急遮断入力機能が働いた状態になっても、主電源が遮断されたわけではありません。製品の確認は、インバータの入力電源を OFF にしてから行ってください。
- 万 one の場合、感電による重度の傷害が起こるおそれがあります。配線変更、モード切替スイッチ (S7, S8) の変更、オプション類の脱着、冷却ファンの交換はインバータの入力電源を OFF にしてから行ってください。

■注意

- 軽度の発火、発熱、機器破損がまれに起こるおそれがあります。端子 (+1, P/+2, N/-) に抵抗器を直接接続しないでください。
- 軽度の傷害がまれに起こるおそれがあります。安全を確保するための停止装置を設置してください。※保持ブレーキは安全を確保するための停止装置ではありません。制動抵抗器や回生制動ユニットの発熱により、中程度のやけどがまれに起こるおそれがあります。必ず指定された制動抵抗器や回生制動ユニットを使用し、制動抵抗器を使用する場合には、抵抗器の温度を監視するサーマルリレーを設置してください。また、制動抵抗器や回生制動ユニットの異常過熱時にインバータの電源を OFF するシーケンスを組んでください。
- 製品内部には高電圧部分があり、短絡させると製品の破損や物的損害がまれに起こるおそれがあります。設置や配線時には切り粉やリード線くすなどの金属物が製品内部に入らないようカバーをつけるなどの処置を行ってください。



3G3JX-A□ SYSDRIVE Inverter

INSTRUCTION MANUAL


Thank you for purchasing 3G3JX Inverter. To ensure the safe operation, please be sure to read the safety precautions provided in this document along with all of the user manuals for the inverter. Please be sure you are using the most recent versions of the user manuals. Keep this instruction manual and all of the manuals in a safe location and be sure that they are readily available to the final user of the products.

Manual Name	Cat.No.
3G3JX User's Manual	I558-E1

OMRON Corporation


©OMRON Corporation 2013 All Rights Reserved. 0193670-5C NT302XE

Names of Parts



Installation and Wiring


■Dimensions



3G3JX-	W	W1	H	H1	D
A2002, AE002	80	67	155	143	95.5
A2004, AE004					109.5
A2007					132.5
A4004, AE007	110	98	189	176	130.5
A2015, A2022, A2037, A4007, A4015, A4022, A4037, AE015, AE022					157.5
A2055, A2075, A4055, A4075					167.5

[mm]

■Standard Connection Diagram



- *1. Connect a single-phase 200V AC input to terminals L1 and N/L3.
- *2. Factory default settings for relay output are NC contact for MA and NO contact for MB.

■Terminal symbols, Screw size and Tightening Torque

Type	Terminal symbol	A2002 ~ A2007 AE002 ~ AE004	A2015 ~ A2037 A4004 ~ A4037 AE007 ~ AE022	A2055 ~ A2075 A4055 ~ A4075
Main circuit	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3 Ground(symbol)	M3.5 0.8N·m (max.0.9N·m)	M4 1.2N·m (max.1.3N·m)	M5 3.0N·m (max.3.3N·m)
Option	N/-, P/+2, +1			
Control circuit	AM, FS, FV, FI, FC, S5, S4, S3, S2, S1, SC, PSC, P24, PC, P1	M2 / 0.2N·m (max.0.25N·m)		
Relay	MA, MB, MC	M2.5 / 0.5N·m (max.0.6N·m)		
Ground	-	M4		M5

For AE□□□, L1, L2, N/L3 are indicated instead of R/L1, S/L2, T/L3 respectively.

Keys

Name	Description
	Switches between the command setting and the data settings, and between the basic function mode and the expended function mode. ■Status transition
	Hold down the Mode key for 3 seconds to jump to 'd001'.
	Changes the set values, parameters and Commands.
	Starts the operation. Forward/Reverse rotation depends on the 'F004' setting.
	Stops the operation. Functions as the Reset key if an error occurs.
	Enters and stores the data.

Parameter No.	Function name	Monitor or data range
d001	Output frequency monitor	0.0 to 400.0
d002	Output current monitor	0.0 to 999.9
d003	Rotation direction monitor	F: forward/ o: stop/ r: reverse
d004	PID feedback value monitor	0.00 to 9999. (Valid when the PID function is selected.)
d007	Output frequency monitor (after conversion)	0.00 to 9999. (Output frequency x conversion factor of b086)
d013	Output voltage monitor	0. to 600.
d016	Total RUN time	0. to 9999.
d017	Power ON time monitor	0. to 9999.
d018	Fin temperature monitor	0.0 to 200.0
d080	Fault frequency monitor	0. to 9999.
d081	Fault monitor1 (latest)	Error code (condition of occurrence) →
d082	Fault monitor2	Output frequency → Output current →
d083	Fault monitor3	Internal DC voltage → RUN time → ON time
d102	DC voltage monitor	0.0 to 999.9
d104	Electric thermal monitor	0.0 to 100.0
F001	Output frequency setting / monitor	Starting frequency to max. frequency
F002 / F202	Acceleration time1/ 2nd acceleration time1	0.01 to 3000.
F003 / F203	Deceleration time1/ 2nd deceleration time1	0.01 to 3000.
F004	Operator rotation direction selection	00: forward/ 01: reverse
A001 / A201	Frequency reference selection/ 2nd frequency reference selection	00: Digital Operator (volume)/ 01: Terminal/ 02: Digital Operator (F001)/ 03: Modbus communication/ 10: Frequency operation result
A002 / A202	RUN command selection/ 2nd RUN command selection	01: Terminal/ 02: Digital Operator/ 03: Modbus communication
A003 / A203	Base frequency/ 2nd base frequency	30 to max. frequency [A004/A204]
A004 / A204	Maximum frequency/ 2nd maximum frequency	30. to 400.
A005	FV/FI selection	02: Switch between FV/ Volume via terminal AT 03: Switch between FI/ Volume via terminal AT 04: FV input only/ 05: FI input only
A020 / A220	Multi-step speed reference0/ 2nd multi-step speed reference0	0.0/ Starting frequency to max. frequency
A021 to A035	Multi-step speed reference1 to 15	0.0/ Starting frequency to max. frequency
A038	Jogging frequency	0.00/ Strating frequency to 9.99
A039	Jogging stop selection	00: Free run on jogging stop 01: Deceleration stop on jogging stop 02: DC injection braking on jogging stop
A045 / A245	Output voltage gain/ 2nd output voltage gain	20. to 100.
A097	Acceleration pattern selection	
A098	Deceleration pattern selection	00: Line/ 01: S-shape curve
b001	Retry selection	00: Alarm/ 01: 0Hz start 02: Frequency matching start 03: Trip after frequency matching deceleration stop
b002	Allowable momentary power interruption time	0.3 to 25.0
b083	Carrier frequency	2.0 to 12.0
b084	Initialization selection	00: Clear the trip monitor 01: Initialize data 02: Clear and initialize
b130	Overvoltage LAD stop function	00: Disable/ 01: Enable
b131	Overvoltage LAD stop function level	200V class: 330 to 395 400V class: 660 to 790

Parameter No.	Function name	Monitor or data range
C001 / C201	Multi-function input1 selection/ 2nd multi-function input1 selection	00: FW(forward)/ 01: RV(reverse)/ 02: CF1(multi-step speed setting binary1)/ 03: CF2(multi-step speed setting binary2)/ 04: CF3(multi-step speed setting binary3)/ 05: CF4(multi-step speed setting binary4)/ 06: JG(jogging)/ 07: DB(external DC injection braking)/ 08: SET(2nd control)/ 09: 2CH(2-step acceleration/deceleration)/ 11: FR3(free run stop)/ 12: EXT(external trip)/ 13: USP(USP function)/ 15: SFT(soft lock)/ 16: AT(analog input switch)/ 18: RS(reset)/ 19: PTC(thermistor input)/ 20: STA(3-wire start)/ 21: STP(3-wire stop)/ 22: F/R(3-wire forward/reverse)/ 23: PID(PID enable/disable)/ 24: PIDC(PID integral/reset)/ 27: UP(UP/DWN function accelerated)/ 28: DWN(UP/DWN function decelerated)/ 29: UDC(UP/DWN function data clear)/ 31: OPE(forward operator)/ 50: ADD(frequency addition)/ 51: F-TM(forced terminal block)/ 52: RDY(ready function)/ 53: SP-SET(special 2nd function)/ 64: EMR(emergency shut off)/ 255: No function
C002 / C202	Multi-function input2 selection/ 2nd multi-function input2 selection	
C003 / C203	Multi-function input3 selection/ 2nd multi-function input3 selection	
C004 / C204	Multi-function input4 selection/ 2nd multi-function input4 selection	
C005 / C205	Multi-function input5 selection/ 2nd multi-function input5 selection	
C011 to C015	Multi-function input 1 ~ 5 operation selection	00: N.O. 01: N.C.
C021	Multi-function output terminal P1 selection	00: RUN(during RUN)/01:FA1(constant speed reached)/ 02: FA2(set frequency min. reached)/ 03: OL(overload warning)/ 04: OD(PID excessive deviation)/ 05: AL(alarm output)/ 06: Dc(disconnection detected)/ 07: FBV(PID FB value output)/ 08: NDC(Network error)/ 09: LOG(logic operation output)/ 10: ODC(communication option, disconnected)/ 43: LOC(light load deflection)
C026	Relay output (MA,MB) function selection	
C028	AM selection	00: Output frequency/ 01: Output current
C031	Multi-function output Terminal P1 contact selection	00: NO contact at MA, NC contact at MB 01: NC contact at MA, NO contact at MB
C036	Relay output (MA,MB) contact selection	
H003 / H203	Motor capacity selection/ 2nd motor capacity selection	200V class: 0.2 to 7.5 400V class: 0.4 to 7.5
H004 / H204	Motor pole number selection/ 2nd motor pole number selection	2/ 4/ 6/ 8

Safety Precautions

■Indications and Meanings of Safety Information

In this user's Manual, the following precautions and signal words are used to provide information to ensure the safe use of the 3G3JX Inverter.

The information provided here is vital to safety. Strictly observe the precautions provided.

■Meanings of Signal Words

	WARNING	Indicates an imminently hazardous situation which, if not avoided, is likely to result in serious injury or death. Additionally there may be severe property damage.
	CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

■Alert Symbols in this Document

		WARNING
	Turn off the power supply and implement wiring correctly. Not doing so may result in a serious injury due to an electric shock.	
	Wiring work must be carried out only by qualified personnel. Not doing so may result in a serious injury due to an electric shock.	
	Be sure to ground the unit. Not doing so may result in a serious injury due to an electric shock or fire. (200V class:type-D grounding, 400V class:type-C grounding)	
	Do not remove the front cover during the power supply and 5 minutes after the power shutoff. Doing so may result in a serious injury due to an electric shock.	
	Do not operate the Operator or switches with wet hands. Doing so may result in a serious injury due to an electric shock.	
	Inspection of the Inverter must be conducted after the power supply has been turned off. Not doing so may result in a serious injury due to an electric shock. The main power supply is not necessarily shut off even if the emergency shut off function is activated.	
	Do not change wiring, mode change switches(S7, S8), optional devices or replace cooling fans while power is being supplied. Doing so may result in a serious injury due to an electric shock.	

CAUTION

	Do not connect resistors to the terminals (+1, P/+2, N/-) directly. Doing so might result in a small-scale fire, heat generation or damage to the unit.
	Install a stop motion device to ensure safety. Not doing so might result in a minor injury. (A holding brake is not a stop motion device designed to ensure safety.)
	Be sure to use a specified type of braking resistor / regenerative braking unit. In case of a braking resistor, install a thermal relay that monitors the temperature of the resistor. Not doing so might result in a moderate burn due to the heat generated in the braking resistor / regenerative braking unit. Configure a sequence that enables the Inverter power to turn off when unusual overheating is detected in the braking resistor / regenerative braking unit.
	The Inverter has high voltage parts inside which, if short-circuited, might cause damage to itself or other property. Place covers on the openings or take other precautions to make sure that no metal objects such as cutting bits or lead wire scraps go inside when installing and wiring.
	Do not touch the Inverter fins, braking resistors and the motor, which become too hot during the power supply and for some time after the power shutoff. Doing so may result in a burn.
	Take safety precautions such as setting up a molded-case circuit breaker(MCCB) that matches the Inverter capacity on the power supply side. Not doing so might result in damage to property due to the short circuit of the load.
	Do not dismantle, repair or modify the product. Doing so may result in an injury.

Precautions for Safe Use

Installation and Storage

Do not store or use the product in the following places.

- Locations subject to direct sunlight.
- Locations subject to ambient temperature exceeding the specifications.
- Locations subject to relative humidity exceeding the specifications.
- Locations subject to condensation due to severe temperature fluctuations.
- Locations subject to corrosive or flammable gases.
- Locations subject to exposure to combustibles.
- Locations subject to dust (especially iron dust) or salts.
- Locations subject to exposure to water, oil, or chemicals.
- Locations subject to shock or vibration.

Transporting, Installation and Wiring

- Do not drop or apply a strong impact on the product. Doing so may result in damaged parts or malfunction.
- Do not hold by the front cover, but hold by the fins during transportation.
- Do not connect an AC power supply voltage to the control input / output terminals. Doing so may result in damage to the product.
- Be sure to tighten the screws on the terminal block securely. Wiring work must be done after installing the unit body.
- Do not connect any load other than a three-phase inductive motor to the U, V and W output terminals.
- Take sufficient shielding measures when using the product in the following locations. Not doing so may result in damage to the product.
 - Locations subject to static electricity or other forms of noise.
 - Locations subject to strong magnetic fields.
 - Locations close to power lines.

Operation and Adjustment

- Be sure to confirm the permissible range of motors and machines before operation because the inverter speed can be changed easily from low to high.
- Provide a separate holding brake if necessary.

Maintenance and Inspection

- Be sure to confirm safety before conducting maintenance, inspection or parts replacement.

Precautions for Correct Use

Installation

- Mount the product vertically on a wall or on a DIN Rail(optional) with the product' s longer sides upright. The material of the wall has to be nonflammable such as a metal plate.

Main Circuit Power Supply

- Confirm that the rated input voltage of the Inverter is the same as AC power supply voltage.

Error Retry Function

- Do not come close to the machine when using the error retry function because the machine may abruptly start when stopped by an alarm.
- Be sure to confirm the RUN signal is turned off before resetting the alarm because the machine may abruptly start.

Non-Stop Function at Momentary Power Interruption

- Do not come close to the machine when selecting restart in the non-stop function at momentary power interruption selection(b050) because the machine may abruptly start after the power is turned on.

Operation Stop Command

- Provide a separate emergency stop switch because the STOP Key on the Operator is valid only when function settings are performed.
- When checking a signal during the power supply and the voltage is erroneously applied to the control input terminals, the motor may start abruptly. Be sure to confirm safety before checking a signal.

Product Disposal

- Comply with the local ordinance and regulations when disposing of the product.

UL Cautions

The warnings and instructions in this section summarizes the procedures necessary to ensure an inverter installation complies with Underwriters Laboratories guidelines.

- Use 60/75°C Cu wire only. (For models: A2015, A2022, A2037, A2055, A2075, AE007, AE015, AE022)
- Use 75°C Cu wire only. (For models: A2002, A2004, A2007, A4022, A4037, A4055, A4075, AE002, AE004)
- Use 60°C Cu wire only. (For models: A4004, A4007, A4015)
- Open Type Equipment.
- Suitable for use on a circuit capable of delivering not more than 100k rms symmetrical amperes, 240 V maximum when protected by Class J fuses. (For models: -A2055 and -A2075)
- Suitable for use on a circuit capable of delivering not more than 100k rms symmetrical amperes, 240V maximum when protected by Class CC, G, J or R fuse or circuit breaker having an interrupting rating not less than 100,000 rms symmetrical amperes, 240 volts maximum. (For models: 200V class except models with -A2055 or -A2075)
- Suitable for use on a circuit capable of delivering not more than 100k rms symmetrical amperes, 480V maximum when protected by Class CC, G, J or R fuse or circuit breaker having an interrupting rating not less than 100,000 rms symmetrical amperes, 480 volts maximum. (For models: 400V class)
- Install device in pollution degree 2 environment.
- Maximum Surrounding Air Temperature 50°C.
- Caution-Risk of electric shock, capacitor discharge time is at least 5 minutes.
- Solid State motor overload protection is provided in each model.
- Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electric Code and any additional local codes.
- Motor over temperature protection is not provided by the drive.

AVERTISSEMENT: ne retirez pas le capot avant pendant l'alimentation et 5 minutes après l'arrêt de l'alimentation. Cela peut entraîner de grave blessure due à un choc électrique.

Terminal Tightening Torque and Wire Size


The wire size range and tightening torque for field wiring terminals are presented in the tables below.

Input Voltage	Motor Output		Inverter Model (3G3JX-)	Power Terminal Wiring Size Range (AWG)	Torque	
	kW	HP			Ft.-lbs	(N-m)
200V (class)	0.2	1/4	A2002/AE002	14 (75°C only)	0.6	0.8
	0.4	1/2	A2004/AE004			
	0.75	1	A2007			
	0.75	1	AE007			
	1.5	2	A2015	12	0.9	1.2
	1.5	2	AE015			
	2.2	3	A2022			
	2.2	3	AE022			
400V (class)	3.7	5	A2037	10	2.3	3.0
	5.5	7 1/2	A2055			
	7.5	10	A2075	8	2.3	3.0
	0.4	1/2	A4004			
	0.75	1	A4007	16 (60°C only)	0.9	1.2
	1.5	2	A4015			
	2.2	3	A4022	14 (75°C only)	2.3	3.0
3.7	5	A4037				
5.5	7 1/2	A4055	12	2.3	3.0	
7.5	10	A4075				

Terminal Conector	Wiring Size Range(AWG)	Torque	
		Ft.-lbs	(N-m)
Logic and Analog connectors	30-16	0.16-0.19	0.22-0.25
Relay connector	30-14	0.37-0.44	0.5-0.6

Wire Connectors

Field wiring connections must be made by a UL Listed and CSA certified ring lug terminal connector sized for the wire gauge being used. The connector must be fixed using the crimping tool specified by the connector manufacturer.



Circuit breaker and Fuse Size

The Inverter' s connection to input power must include UL Listed inverse time circuit breakers with 600V rating, or UL Listed fuses as shown in the table below.

Input Voltage	Inverter Model (3G3JX-)	Circuit Breaker / Fuse	Rated Current (A)
200V (class)	A2002/AE002	Inverse time circuit Breaker	10
	A2004/AE004		15
	A2007/AE007		
	A2015		
	AE015		
	A2022		
	AE022		
400V (class)	A2037	Distribution Fuse (Class J)	40
	A2055		50
	A2075		3
	A4004		6
	A4007		10
	A4015	Inverse time circuit Breaker	15
	A4022		20
	A4037		25
	A4055		
	A4075		

Motor Overload Protection

3G3JX Inverters provide solid state motor overload protection, which depends on the proper setting of the following parameters .

- b012 : electronic overload protection
- b212 : electronic overload protection, 2nd motor

Set the rated current [Amperes] of the motor(s) with the above parameters. The setting range is 0.2 rated current to 1.0 rated current.

When two or more motors are connected to the Inverter, they cannot be protected by the electronic overload protection. Install an external thermal relay on each motor.

Conformance to EU Directives

- For earthing, selection of cable, and any other conditions for EMC-compliance, please refer to the User' s manual for installation.
- This is a class A product in residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.

3G3JX series Inverter has integrated EMC filter as shown below

- 200V class : EN61800-3 category C1
- 400V class : EN61800-3 category C2

OMRON Corporation

Shiokoji Horikawa, Shimogyo-ku, Kyoto, 600-8530, Japan

Omron Europe B.V.

Wegalaan 67-69, NL-2132 JD Hoofddorp, The Netherlands

For KC Marking Only

A 급 기기 (업무용 방송통신기자재)
이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

SUITABILITY FOR USE

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the product in the buyer's application or use of the product.

At buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the product. This information by itself is not sufficient for a complete determination of the suitability of the product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

OMRON

OMRON Corporation Industrial Automation Company
Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters
OMRON EUROPE B.V.
Wegalaan 67-69, NL-2132 JD
Hoofddorp
The Netherlands
Tel: (31)2356-81-300
Fax: (31)2356-81-388

OMRON ELECTRONICS LLC
One Commerce Drive Schaumburg,
IL 60173-5302 U.S.A.
Tel: (1) 847-843-7900
Fax: (1) 847-843-7787

OMRON ASIA PACIFIC PTE. LTD.
No. 438A Alexandra Road # 05-05/08
(Lobby 2), Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011
Fax: (65) 6835-2711

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
Pu Dong New Area, Shanghai,
200120, China
Tel: (86) 21-5037-2222
Fax: (86) 21-5037-2200