

AC Servo System 1S-series with Built-in SS1/SLS Safety Sub-Functions

Startup Guide

CK3M/CK5M CPU Unit (Programmable Multi-axis Motion Controller) for Connection

R88M-1L□/-1M□ (AC Servomotor) R88D-1SN□-ECT-51 (AC Servo Drive) CK3M/CK5M CPU Unit (Programmable Multi-axis Motion Controller) NX-series Safety Units Sysmac Studio Power PMAC IDE

Startup Guide



I929-E1-01

NOTE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Introduction

The AC Servo System 1S-Series Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions Startup Guide (hereinafter, may be referred to as "this Guide") describes the installation and setup of 1S-series Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions (hereinafter, may referred to as "1S-51"). This Guide assumes a system that consists of a combination of a Programmable Multi-axis Motion Controller CK3M/CK5M CPU Unit, a 1S-series AC Servomotor/Servo Drive with Built-in SS1/SLS Safety Sub-Functions, an NX-series Safety Control Unit, the Sysmac Studio, and the Power PMAC IDE. A simple installation model is used for the discussion. You can perform the procedures that are presented in this Guide to quickly gain a basic understanding of 1S-series AC Servomotor/Servo Drive with Built-in SS1/SLS Safety Sub-Functions.

Note that this Guide does not contain safety information and other details that are required for actual use. Thoroughly read and understand the manuals for all of the devices that are used in this Guide to ensure that the system is used safely. Review the entire contents of these materials, including all safety precautions, precautions for safe use, and precautions for correct use.

Intended Audience

This Guide is intended for the following personnel.

- · Personnel in charge of introducing FA systems
- · Personnel in charge of designing FA systems

The personnel must also have the following knowledge.

- . Knowledge of electrical systems (an electrical engineer or the equivalent)
- Knowledge of Programmable Multi-axis Motion Controller CK3M/CK5M CPU Units
- Knowledge of NX-series Safety Units
- Knowledge of AC Servomotors/Drives
- Knowledge of operation procedure of Sysmac Studio and Power PMAC IDE

Applicable Products

This Guide covers the following products.

- Programmable Multi-axis Motion Controller CK3M/CK5M CPU Unit
- Automation Software Sysmac Studio
- Power PMAC Software Package Power PMAC IDE
- . 1S-series Servomotor/Servo Drive with Built-in SS1/SLS Safety Sub-Functions
- NX-series EtherCAT Coupler Unit
- NX-series Safety Control Unit

Special Information

Special information in this Guide is classified as follows:

Precautions for Correct Use

Precautions on what to do and what not to do to ensure safe usage of the product.

Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

Terms and Conditions Agreement

Warranties

(a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

(b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy.

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <u>http://www.omron.com/global/</u> or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the

Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Precautions

- When building a system, check the specifications for all devices and equipment that will make up the system and make sure that the OMRON products are used well within their rated specifications and performances. Safety measures, such as safety circuits, must be implemented in order to minimize the risks in the event of a malfunction.
- Thoroughly read and understand the manuals for all devices and equipment that will make up the system to ensure that the system is used safely. Review the entire contents of these materials, including all safety precautions, precautions for safe use, and precautions for correct use.
- Confirm all regulations, standards, and restrictions that the system must adhere to.
- Check the user program for proper execution before you use it for actual operation.

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Windows is either a registered trademark or trademark of Microsoft Corporation in the USA and other countries.
- EtherCAT[®] is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- Safety over EtherCAT[®] is a registered trademark and a patented technology licensed by Beckhoff Automation GmbH, Germany.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.
- Other company names and product names in this Guide are the trademarks or registered trademarks of their respective companies.

Software Licenses and Copyrights

The Sysmac Studio incorporates certain third party software. For the license and copyright information associated with this software, please refer to <u>NJ/NX/NY series/Sysmac Studio</u>: <u>Third Party License List & Source code Download: Tools: OMRON (omron.co.jp)</u>.

Related Manuals

Manual name	Cat. No.	Model	Application	Description
1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub- Functions User's Manual	1696	R88D-1S□-ECT-51 R88M-1□	Learning detailed specifications of a 1S- series Servo Drive with Built-in SS1/SLS Safety Sub-Functions.	Describes how to install and wire the Servo Drive, set parameters needed to operate the Servo Drive, and remedies to be taken and inspection methods to be used in case that problem occur.
Version 1 Operation Manual	VV504	SYSMAC-SEZUUU	operating about the operating procedures and functions of the Sysmac Studio.	operating procedures of the Sysmac Studio.
Sysmac Studio Drive Functions Operation Manual	1589	SYSMAC-SE2	Learning how to set up and adjust the Servo Drives.	Describes the operating procedures of the Sysmac Studio.
NX series EtherCAT Coupler Unit User's Manual	W519	NX-ECC201 NX-ECC202 NX-ECC203	Learning how to use the EtherCAT [®] Coupler Units.	Describes the hardware, setup methods and functions of the EtherCAT [®] Coupler Units.
NX Series Digital I/O Units User's Manual	W521	NX-ID	Learning how to use the NX-series Digital I/O Units.	Describes the hardware, setup methods and functions of the NX-series Digital I/O Units.
NX Series System Units User's Manual	W523	NX-PD1 NX-PF0 NX-PC0 NX-TBX01	Learning how to use the NX-series System Units.	Describes the hardware, setup methods and functions of the NX-series System Units.
NX-series Safety Control Units User's Manual	Z930	NX-SLOOOO NX-SIOOOOO NX-SOOOOO	Learning how to use the NX-series Safety Control Units.	Describes the hardware, setup methods and functions of the NX-series Safety Control Units.
Programmable Multi-Axis Controller User's Manual (Hardware)	O036	CK5M-CPU1 1 CK3M-CPU1 1 CK3W-PD048 1 CK3W-AX1313 1 AX1414 1 AX1515 1 AX1515 1 CK3W-MD71 0 CK3W-AD 100 CK3W-ECS300 00 CK3W-ECS300 00 CK3W-EXM01/- 1 EXS02 0 CK5W-EXS01 0	Learning how to use the CK3M/CK5M- series Programmable Multi-axis Motion Controllers.	Describes the hardware, setup methods and functions of the CK3M/CK5M- series Programmable Multi-axis Motion Controller.
Power PMAC IDE Software User Manual		Power PMAC IDE	Learning how to use the Power PMAC IDE.	Describes the operating procedures of the Power PMAC IDE

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content			
01	February 2025	Original production			

CONTENTS

Introduction	1	3
Intended A	Audience	
Applicable	Products	
Special In	formation	4
Terms and	Conditions Agreement ······	5
Precautions	5	7
Trademar	<s< td=""><td>7</td></s<>	7
Software I	Licenses and Copyrights	7
Related Ma	nuals	
Revision Hi	story ·····	9
1. Servo S	System Configuration and Peripheral Products	12
1.1. Ou	tline	12
1.2. Se	rvo System Constructed in This Guide	13
1.3. Sy	stem Configuration	14
2. Before	You Begin ·····	16
3. Perforn	ning Setup ·····	18
3.1. Ins	tallation and Wiring	20
3.2. Sy	stem Configuration with NX-series Safety Control Units	
3.3. Se	tup of NX-series Safety Control Units	29
3.3.1.	Creating a Network Configuration	29
3.3.2.	Setting to Transfer Data from the Standard Controller to	
	the Safety Controller	33
3.3.3.	Setting the Safety Controller	34
3.3.4.	Creating a Safety Program	37
3.4. Se	tup of the Motion Controller CK5M	46
3.4.1.	Preparing the Controller for Setup	46
3.4.2.	Installing the ESI File	51
3.4.3.	Configuring EtherCAT Communications Settings	52
3.4.4.	Setting Axis Variables	62
3.4.5.	Creating an Operation Program	64
3.4.6.	Downloading the Project and Checking the Operation	66
3.5. Se	tup of the Servo Drive	68
3.5.1.	Connecting the Servo Drive via CK5M	68
3.5.2.	Motor, ABS Encoder and I/O Setup	69
3.6. Op	eration Check of the STO Function	
4. Adding	Safety Functions	73
4.1. Ad	ding the Safe Stop 1 (SS1) Function	
4.1.1.	Setting the Safety Controller	
4.1.2.	Setup of the CK5M	80
4.1.3.	Checking Operation of the SS1 Function	

Adding the Safely-limited Speed (SLS) Function					
.1. Setting the Safety Controller					
2. Setup of the CK5M					
3. Checking Operation of the SLS Functions					
lices ·····	100				
Test Run and Data Trace10					
Easy Tuning					
Manual Tuning					
nced Auto-Tuning					
	Adding the Safely-limited Speed (SLS) Function 1. Setting the Safety Controller 2. Setup of the CK5M 3. Checking Operation of the SLS Functions ices Funing al Tuning ced Auto-Tuning				

1. Servo System Configuration and Peripheral Products

1.1. Outline

The 1S-series Servo Drives with Built-in EtherCAT[®] Communications and SS1/SLS Safety Sub-Functions support 100-Mbps EtherCAT.

When you use the 1S-series Servo Drive with a Machine Automation Controller NJ-series CPU Unit or a Programmable Multi-axis Motion Controller CK3M/CK5M CPU Unit, you can construct a high-speed and so sophisticated position control system.

You need only one communications cable to connect the Servo Drive and the Controller. Therefore, you can realize a position control system easily with reduced wiring effort.

With tuning functions, adaptive notch filter, notch filter, and damping control, you can set up a system that provides stable operation by suppressing vibration in low-rigidity machines.

The 1S-series Servo Drives with Built-in EtherCAT[®] Communications and SS1/SLS Safety Sub-Functions support the FSoE (Safety over EtherCAT) protocol as a safety communications feature. You can build a safety system that uses the STO, SS1, and SLS functions from NX-series Safety Control Units on an EtherCAT network.



Additional Information

For further details on the 1S-series Servo Drives with Built-in EtherCAT[®] Communications and SS1/SLS Safety Sub-Functions, refer to the *1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual* (Cat. No. 1696).

This Guide contains instructions from assembling the hardware that makes up a servo system to constructing a system for safety functions and performing debugging on the system. The servo system is built through the following steps:





Additional Information

For information on how to set up the motion controller, refer to the Programmable Multi-Axis Controller User's Manual (Hardware) (Cat. No. 0036).

1.3. System Configuration

The following figure shows the system configuration and devices that are used in this Guide.

• Standard System Configuration



• Configuration Devices

The models of the devices that are described in this Guide are given in the following table. When selecting devices for an actual application, refer to the device manuals.

Device name	Model	Manual name
Programmable Multi-axis Motion	CK5M	Programmable Multi-axis Motion
Controller CK5M CPU Unit		Controller Hardware User's Manual
(Standard controller)		
EtherCAT Coupler	NX-ECC20[]	EtherCAT [®] Coupler Unit User's
		Manual (Cat. No. W519)
Additional I/O Power Supply Unit	NX-PF0[]	NX Series System Units User's
		Manual (Cat. No. W523)
Digital Input Unit	NX-ID[]	NX Series Digital I/O Units User's
		Manual (Cat. No. W521)
NX-series Safety Control Unit	NX-SL3500	NX-series Safety Control Units User's
(Safety controller)		Manual
NX-series Safety Input Unit	NX-SID[]	(Z930)

Device name	Model	Manual name
Ethernet/EtherCAT	XS5W-T[]	
Communications Cable		
AC Servo Drive	R88D-1SN[]-51	1S-series AC Servomotors/Servo
AC Servomotor	R88M-1[]	Drives with Built-in EtherCAT
Power Cable	R88A-CA[]	Communications and SS1/SLS Safety
Encoder Cable	R88A-CR[]	Sub-Functions User's Manual
		(Cat. No. I696)
Error clear button	A3[]	
Safety Key Selector Switch	A22TK[]	
Safety-door Switch	D4NS[]	
Emergency Stop Pushbutton Switch	A22[]	

Automation Software

Product	Number of licenses	Model		
Sysmac Studio Standard Edition	None (DVD only)	SYSMAC-SE200D		
Version 1.59.0.0	From 1 license to site license	SYSMAC-SE[]		
Power PMAC IDE				
Version 4.6.4 or later				

Additional Information

This Startup Guide is written on the assumption that you will use the safety functions. If you do not use the safety functions, refer to sections 5 and 6 of the Programmable Multi-Axis Controller Startup Guide for 1S-series Servo Drive (IDEv4) (Cat. No. 0039).

2. Before You Begin

Unpacking



Additional Information

For further details on how to handle the Servo Drive and Servomotor, refer to the *Items* to Check After Unpacking in the 1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual (Cat. No. 1696).

■ Installing the Sysmac Studio Standard Edition Version 1.59

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on how to install the Sysmac Studio.



■ Installing Power PMAC IDE Version 4.6.4 or Later

Refer to the *Power PMAC IDE Software User Manual* (V4) for the download procedure.

Note: The setup procedures described in this Startup Guide are available only when the language setting of the Power PMAC IDE is *English*. After installing the Power PMAC IDE, change the language setting to *English*.

3. Performing Setup

This section explains from assembling the hardware that makes up the servo system to adding the STO function via FSoE and creating a motor control program. The next section <u>4. Adding Safety</u> <u>Functions</u> describes how to add safety functions other than the STO function.

The operation of the servo system set up in this section is explained below.

- 1. When the error clear button is pressed, the errors of the standard controller and Servo Drive are reset.
- 2. When the guard with the Safety-door Switch is opened, the motor torque is turned OFF.
- 3. When the Emergency Stop Pushbutton Switch is pressed, the motor torque is turned OFF.
- 4. When the safety reset button is pressed, the STO status is reset.



Input device	State	Operation		
1. Error clear button	ON	Enable error reset command		
	OFF	Disable error reset command		
2 Safety Key Selector	Normal operating	Set the Servomotor to normal velocity.		
2. Salety Key Selector	mode			
* Used in section 4 and later	SS1/SLS safety	Activate assigned safety function.		
Used In section 4 and later.	function active	* The assignment procedure is described in section 4.		
3. Safety-door Switch	Open	Enable STO command		
	Close	Disable STO command		
4. Emergency Stop	ON	Enable STO command		
Pushbutton Switch	OFF	Disable STO command		
5. Safety reset button	ON	Enable reset STO status command		
	OFF	Disable reset STO status command		

- Operation of STO Function with Motion Control
- 1. When the Servo ON command is enabled, the Servo Drive turns ON the Servo.
- 2. When the STO function is executed, the Servo Drive shifts to the STO state and turns OFF torque.
- 3. When an operation command is enabled, the command velocity to the Servomotor is set to 1,200 r/min.



3.1. Installation and Wiring

This section describes the installation and wiring of the AC Servo Drive, using the R88D-1SN01L-ECT-51 as an example.

For models for which the installation and wiring procedures differ from those for the R88D-1SN01L-ECT-51, refer to the 1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual (Cat. No. 1696).



- *1. If S2 must be less than 10 mm, keep the operating ambient temperature of the Servo Drive within 0 to 45°C.
- Install the Servo Drive on the vertical metal surface.
- To provide electrical conduction, remove any paint from the surface on which you install the Servo Drives. Also, it is recommended that you apply conductive plating if you make the mounting bracket by yourself.
- The recommended tightening torque for installing the Servo Drive is 1.5 N·m. Make sure that the threaded portion has the sufficient strength to withstand the recommended torque.

Mounting the Servo Drive





Additional Information

For further details on how to connect the cables, refer to 4-1 Installation Conditions in the 1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual (Cat. No. 1696).

Wiring





Additional Information

For further details on how to make the wiring, refer to 4-2 *Wiring* in the 1S-series AC *Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual* (Cat. No. 1696).

I/O and Safety Wiring







Additional Information

For further details on how to make the wiring, refer to 8-2 Safe Torque OFF (STO) Function in the 1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual (Cat. No. 1696).

3.2. System Configuration with NX-series Safety Control Units

EtherCAT Node Address Configuration

Additional Information

For further details on the safety controller, refer to the NX-series Safety Control Unit User's Manual (Cat. No. Z930).

3.3. Setup of NX-series Safety Control Units

Set up the NX-series Safety Control Units using the Sysmac Studio.

To do so, connect the computer via USB to the coupler unit in the system configuration described in <u>3.2 System Configuration with NX-series Safety Control Units</u>, as shown below.

3.3.1. Creating a Network Configuration

1.	Select the NJ501-1500 Controller from Select Device.
	Version 1.64
	Note: Create a project using the default settings for Device and Version , as these
	settings do not allect the configuration being created.
	Multiview Explorer
	The EtherCAT Tab Page is displayed in the Edit Pane.
	Materia Grand Materia Materia Materia

Additional Information

If the physical EtherCAT network configuration is already connected, you can automatically create the virtual network configuration on the Sysmac Studio from the physical network configuration.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for the procedure.

3.3.2. Setting to Transfer Data from the Standard Controller to the Safety Controller

3.3.3. Setting the Safety Controller

This section describes how to set safety input devices and create a safety program to release STO.

9.	Double-click SRA Parameters.									
	Multiview Explo rew_Safety: Configure to Configure to Con	DPUD ▼ ions and Set mmunicatio Safety ↓ Safety I ↓ Safety I	tup //O /a1 - BRBD_10 //O SERA Parameters O O osed Variable	AM11 - ECT-51 (E_Axis0 : Instance0) ers						
10.	Deactiva	ate sa	afety	functions excep	ot fo	or the ST	O function.			
	Clear th	e Act	tive C	heck Box for S	S1	instance	1 to deactiv	ate the	unused sat	fety
	function	_								
	🖨 I/O Map	SRA P	arameters	×		_		_		
	Safety Functions Assignment Settings									
	SS1									
		No.	Active	Safety Functions		Details	Command	i	Status	
		0		STO	-		STO	-	STO Active	
	SLS	1		SS1 instance1			SS1 command1	~	Reserved	*
		2		Reserved			Reserved		Reserved	T
		3		Reserved			Reserved	~	Reserved	T
		4		Reserved	1		Reserved		Reserved	*
		5		Reserved			Reserved		Reserved	
		6		Keserved			Keserved	20	Reserved	
		<i>'</i>		Error ACK		- 644	Error Ack		Error Net Assisted	
		0		Net Assigned	H		Not Assigned		Not Assigned	
3.3.4. Creating a Safety Program

- Create a safety program by following the steps below:
- 1. Create device variables.
- 2. Create a safety program using the Automatic Programming function.
- 3. Modify the created safety program.

1. Create device variables.



1.	Click Automatic Programming from the Insert Menu.
	File Edit View Insert Project Controller Nut V Image: Controller Application Amager Application Amager Multiview Explorer Safety Network Controller Image: Controler Image:
2.	Set the reset signal to SI_ResetSignal in the Basic Settings Field.
3.	Set SI_E-Stop and SI_DoorSwitch in the Input Settings Field.
4.	Set <i>E001_STO</i> in the Output Settings Field. Set the <i>Use EDM</i> Column to <i>TRUE</i> .
	No. Variable Comment Use EDM 1 E001_STO TRUE Image: Comment in the second secon
5.	No. Variable Comment Use EDM 1 E001_STO TRUE Set the E001_STO Column to 0 for the SI_E-Stop and SI_DoorSwitch variables in the Expected Value Settings Field. Expected Value Settings Field. Variable Comment Reset Type E001_STO 0 0
5.	No. Variable Comment Use EDM 1 E001_STO TRUE Set the E001_STO Column to 0 for the SI_E-Stop and SI_DoorSwitch variables in the Expected Value Settings Field. * Expected Value Settings No. Variable O Set the Generate Button to create a safety program. Automatic Programming × Generate Register Variables

2. Create a safety program using the Automatic Programming function.

3. Modify the created safety program.











13.	Download the safety application.
	Select <i>new_SafetyCPU0</i> from the list.
	new_Controller_0
	Click the PROGRAM Mode Button to switch to PROGRAM mode.
	Click the DEBUG Mode Button to enter DEBUG mode.
	DEBUG Mode
	Click the DEBUG Mode Button to start DEBUG mode.
	DEBUG Mode
	Click the Safety Validation Button.
	Safety Validation
	The safety application is now ready to run.
	Safety Validation
	Safety CPU Unit will start in RUN mode on next startup
	Click the RUN Mode Button.
	、 🔺 名 紹 💽 💺 🖷 🖏 🌾 当 RUN Mode



3.4. Setup of the Motion Controller CK5M

To prepare for setting up the CK5M, use the Power PMAC IDE. Install the Power PMAC IDE on the computer in advance, with reference to <u>2. Before You</u> <u>Begin</u>.

3.4.1. Preparing the Controller for Setup

1. 2.	Turn ON the power supply to the Controller
2.	Turn ON the power supply to the Controller.
	Start the Power PMAC IDE.
	Note: If a dialog box for access right confirming is displayed at startup, make selection
	to start the Power PMAC IDE.
3.	In the Communication Setup Dialog Box displayed, specify the IP address of the
	Controller to connect to and click the <i>Connect</i> Button.
	Communication Setup
	IP Address 192 168 0 200
	User: root
	Password:
	Connect Test No Device
	The default ID address of the Controller is 102,169,0,200
	If percentry change the IP address in Windows to 102 168 0 X
	The Power PMAC IDE starts and goes online with the Controller
•	The Power PMAC IDE starts and goes online with the Controller.
	The Power PMAC IDE starts and goes online with the Controller.
	The Power PMAC IDE starts and goes online with the Controller.
-	The Power PMAC IDE starts and goes online with the Controller.
•	The Power PMAC IDE starts and goes online with the Controller.
•	The Power PMAC IDE starts and goes online with the Controller.
•	The Power PMAC IDE starts and goes online with the Controller.
•	The Power PMAC IDE starts and goes online with the Controller.
•	The Power PMAC IDE starts and goes online with the Controller.
-	The Power PMAC IDE starts and goes online with the Controller.
-	<complex-block></complex-block>
-	<complex-block></complex-block>
	<complex-block></complex-block>



■ Initially Setting Up the Controller

Perform the initial setup of the Controller.

Precautions for Correct Use

Save any necessary data in the Controller before proceeding, since the initial setup procedure clears all the memory.



2.	Open System - CPL	- System from the So	olution Ex	kplorer.
	Solution Explorer	* ₽×		
	© © ☆ [™] /	-		
	Search Solution Explorer (Ctr	+:) P -		
	CK5M_StartUpGuide_Sa	imple01		
	▲ System ▲ System			
	👩 System			
	📕 Hardware 🚄 EtherCAT			
	🔶 Master0 (Dea	ctivated)		
	Motors Coordinate System	ms		
	👂 🛑 Encoder			
	Icols			
	Configuration			
	Documentation			
	PMAC Script Langua	ige		
3.	Click the Clock Setti	<i>ngs</i> Button.		
	Clock Settings Com	mon System Elements Memory Buffer:	Core	Management Advanced System
				Elements
4.	Set the Servo Frequ	ency to 1 kHz.		_
	System 🕂 🗙			
	Phase Frequency:	1.000 kHz		
	Servio Frequency:	1.000 × kHz		
	Deal Time Francisco	1.000 × 1/1=		
	Real- lime frequency:	1.000 • KH2		
	Sama Davia di	Existing New	. Millionendo	
	Bhave Over Serve Devia de	1.000		
	Phase Over Servo Period:	1.000		0
	Only EtherCAT detected.			
	PWM / Hardware Sampling Freq	uency re Clock on Power PMAC 🕕		
	Note: The servo free	uencv that you set he	re has th	e following relationship with the
	Servo Drive's comm	unications cycle. Set	he freque	ency according to the
	communications cyc	le you want to set.	·	
	Communication	0		
	cycle [µs]	Servo Frequency	[KHZ]	
	1,000	1.0		
	500	2.0		
	250	4.0		
	125	8.0		

5.	Click the <i>Accept</i> Button.		
	Common System Elements Accept		
6.	If you change the servo frequency setting, enter the save command from the Terminal		
	of the Power PMAC IDE.		
	Terminal.		
	Terminal		
	Welcome to Power PMAC terminal		
	Select Device to start communication SSH communication to Power PMAC at 192.168.0.200 successful		
	\$\$\$ ***		
	Resetting Power PMAC Power PMAC Reset complete		
	save		
	Power PMAC Messages Terminal Output		
7.	Click the Communication Setup icon in the toolbar to display the Communication		
	Setup Dialog Box.		
	File Edit View Debug Tools PowerPMAC EtherCAT Window Help		
	Image: Start Page Image: Communication Setup		
	Watch ♥ Poston C S Command/Query ▲▼ ♥ Status		
	Sys.ServoCount CATIOLEnable Power PMAC Error Power PMAC Unsolicited Power PMAC Unsolicited		
	System 102 NF EC208 1002 602 1 Star		
	isResetButton Save 1002_IXX_ECC203_1002_6662_1_Inp ↓ Update Firmware		
	Slave_1001_R88D_ISN01L_ECT_51_1001_4 ± Install Package Slave_1001_R88D_ISN01L_ECT_51_1001_4 & Device Imaging		
	Motor(1)JogSpeed & Backup Restore Motor(1)AmpEna Tools		
	received: 54 characters; response time Compare		
	Position Veloc #1 1,280,006,237.00000000 mu #1 1,280,006,237.00000000 mu		
8.	Click the <i>No Device</i> Button in the <i>Communication Setup</i> Dialog Box.		
	Communication Setup		
	IP Address: 192.168.0.200 V		
	User: root		
	Passwora:		
	<u>C</u> onnect <u>I</u> est <u>N</u> o Device		
	The Controller goes offline.		
9.	Cycle the power supply to the Controller. The set servo frequency will be reflected		
	after the Controller restarts.		

10.	Wait for the Controller to complete starting up, click <i>Communication Setup</i> in the toolbar to display the Communication Setup Dialog Box.
	Click the Connect button in the Communication Setup Dialog Box.
	Communication Setup ×
	IP Address: 192.168.0.200 V
	User: root
	Password: *******
	Connect Iest No Device
	The Controller goes online.

3.4.2. Installing the ESI File

Install the ESI file for the Servo Drive in the Power PMAC IDE.

Precautions for Correct Use

Prepare the ESI file mentioned in this section in advance. The ESI file can be downloaded from the OMRON website.



3.4.3. **Configuring EtherCAT Communications Settings**



Configuring EtherCAT Master Communications Settings



Configuring Distributed Clock Settings



2.	Select the Bus Shift (Reference Clock controlled by EtherCA	T Master Time) option.
	Slave_1001 [R88D-1SN01L-ECT-51] (1001) Master0 (Deactivated) 🌩 🗙	
	Device Editor Master Topology View Process Data Image Variables Advanced Options Slave to Slave Distributed Clocks Tasks + Sync Un	its
	Reference Clock	
	Name Slave_1001 [R88D-1SN01L-ECT-51] (1001)	
	Clock Adjustment Master Shift (EtherCAT Master Time controlled by Reference Clock) or	
	Link Layer (Reference Clock controlled by Link Layer)	
	Bus Shift (Reference Clock controlled by EtherCAT Master Time) Edit	
	External Mode (Reference Clock controlled by External Sync Device)	
	Uptions 🔲 🔲 Sync Window Monitoring	
	Show 64Bit System Time	
	Slaves with active DC	
	Slave_1001 [R88D-15N01L-ECT-51] (1001) Slave_1002 [NX-ECC203] (1002)	
3	Open Slave 1001 [R88D-1SN01] -ECT-511 (1001) from the S	olution Explorer and
0.	diamley the Distributed Clerk Teh Dare	
	display the Distributed Clock Tab Page.	
	Slave_1001 [R88D-1SN01L-ECT-51] (1001) >> × Master0 (Deactivated)	Solution Explorer - 7 ×
	General Modules PDO Mapping Variables Advanced Options Distributed Clock nit Commands CoE Object-Dictionary Sync Units	Search Solution Explorer (Ctrl+:)
	Distributed Clock	CK5M_StartUpGuide_Sample01 GStartUpGuide_Sample01 GStartUpGuide_Sample01
	Sync Unit Cycle (us) 1000	∠ 🛁 CPU 5) System
	Overwrite Made 📃	I Hardware I ScherCAT
	✓ Sync Units ✓ Sync Unit 0	Master0 (Deactivated) Slave_1001 [R88D-1SN01L-ECT-51] (1001)
	Cycle Time	001 Module 1 (FSoE-SLS) Slave_1002 [NX-ECC203] (1002)
	User defined 1000	001 Module 1 (NX-PF0630) 002 Module 2 (NX-SL3500)
	Shift Time (us)	 003 Module 3 (NX-SID800) 004 Module 4 (NX-ID5342)
	Sync Unit 1 Cycle Time	Motors Coordinate Systems
	Sync Unit Cycle x 1 v 0 us	Encoder Tools
	User defined	Clanguage Configuration
	Shift Time (us)	Documentation Log
		P PMAC Script Language
4.	Set Operation Mode to DC for synchronization.	
	Slave 1001 (R88D-1SN01L-ECT-51) (1001) + × Master0 (Deactivated)	
	Device Editor	
	Convert Markeley DDO Manaire Mariellay Advanced Options Distribu	ited Clock Lait Carear
	General Modules PDO Mapping variables Advanced Options	Init Commi
	Distributed Clock	
	Operation Mode DC for synchronization 🔹	
	Sync Unit Cycle (us) 1000	
	Overwrite Mode	

5.	Similarly, open Slave_1002 [NX-ECC203](1002) from the Solution Explorer and
	display the Distributed Clock Tab Page.
6.	Set Operation Mode to DC for synchronization.
	Slave_1002 [NX-ECC203] (1002) + × Device Editor General Modules PDO Mapping Variables Advanced Options Distributed Clock Init Distributed Clock
	Operation Mode DC for synchronization
	Sync Unit Cycle (us) 1000 Overwrite Mode

■ Configuring PDO Map Settings

Scan Ethe Load Map Activate E Reset Ethe Append S		Solution Explorer Search Solution Explorer (Ctrl+:) Search Solution Explorer (Ctrl+:) Search Solution Explorer (Ctrl+:) A System CPU Hardware Hardware CPU Hardware CPU Hardware CPU CPU CPU CPU CPU CPU CPU CP	2		
Scan Ethe Load Map Activate E Reset Ethe Append S		Search Solution Explorer (Ctrl+:)			
Scan Ethe Load Map Activate E Reset Ethe Append S		Search Solution Explorer (Ctrl+:)			
Scan Ethe Load Map Activate E Reset Ethe Append S		 ✓ System ▶			
Scan Ethe Load Map Activate E Reset Ethe Append S					
Scan Ethe Load Map Activate E Reset Ethe Append S		▲ EtherCAT ▲ Master0			
Load Map Activate E Reset Ethe Append S	erCAT Network	Slave_1001 [R88D-1SN01L-ECT-51] (1001)			
Reset Ethe Append S	pping to Power PMAL	001 Module 1 (FSoE-SLS)			
Append S	eurerca i	001 Module 1 (NX-PF0630)			
Append -	Append Slave Paste Slave	002 Module 2 (NX-SL3500)			
Paste Nav		003 Module 3 (NX-SID800)			
Edit Topo'	bloav	Motors			
Expand A	411	> 🛑 Coordinate Systems			
Collapse /	All	Encoder			
Show Ma	aster Status	C Language			
Watch Eth	herCAT Mapped Variables	Configuration			
Network I	Mismatch Analyzer	Documentation			
Line Cross	ised Analyzer	MAC Script Language			
✓ Configura	ation Mode				
Diagnosis	s Mode	erties 🔫 🖡			
EoE Endp	ioint Configuration	ter0 File Properties			
Import PD	DO from Sysmac file	₽↓ ₽			
Import SR	RA Parameter from Sysmac file	e Name Master0	-		
Import Siz		Name			
Load Map	aves from ENI				
Export EN	laves from ENI pping to Power PMAC from ENI	name of the file or folder			







4.	Open Master0 (Deactivate) fro	m the S	Solution Explorer and c	lisplay t	the Slave_to Slave
	Tab Page.				
	In Connections, check that 1S-	51 and	l SL3500 are linked (in	the rec	l frame), and that
	SID800 and SL3500 are linked	l (in the	e blue frame).		
	Master0 - + ×				
	Master Topology View Process Data Image Variables Advanced Options Sla	ve to Slave Distrib	uted Clocks Tasks + Sync Units		
	Slave to Slave Inputs		Outputs		
	 Slave_1001 [R88D-1SN01L-ECT-51] Slave_1002 [NX-ECC203] 		 Slave_1001 [R88D-1SN01L-ECT-51] Slave_1002 [NX-ECC203] 		
		>>			
		×			
	Connections				
	Input Offset Slave 1002 INK-EC 2031 Module 2 (NK-513500) Input Data Set 1 51	Output	1 IP88D_15M011_FCT_511 Module 1 IF56F_515\17th receive DDO Ma	Offset BitSize	
	Slave_1002 [NX-ECC203]Module 2 [NX-5L3500]input Data Set 1.E002.Slot2.N 64	10 >> Slave 100	2 INX-ECC2031Module 3 (NX-SID800).Output Data Set 1	53.0 56	
	Slave_1001 [R88D-15N01L-ECT-51].Module 1 (FSoE-SL5).17th transmit PDO M 30	0.0 >> Slave_100	2 [NX-ECC203] Module 2 (NX-5L3500).Output Data Set 1	37.0 56	
	Slave_1002 [NX-ECC203].Module 3 (NX-SID800).Input Data Set 1 73	3.0 >> Slave_100	2 [NX-ECC203].Module 2 [NX-5L3500).Output Data Set 1.E002.Slot2.	44.0 56	

Setting the SRA Parameters

Check that the SRA parameters settings of the CK5M match those of the safety controller. For information on setting the safety controller, refer to <u>3.3.3 Setting the Safety Controller</u>.

1.	In the Solution Explorer, righ	nt-click Master0 (Deactiva	ted) and select Import SRA
	Parameter from Sysmac file	from the menu.	
	🖌 🛁 System		
	clear sm pdos (0x1C12) RO		
	dear sm pdos (0x1C13) RO	(Deactivated)	
	Load Mapping to Power PMAC ve	1001 [R88D-1SN012-EC1-51] (1001) _1002 [NX-ECC203] (1002)	
	Activate EtherCAT 00 Recet EtherCAT 00	71 Module 1 (NX-PF0630) 22 Module 2 (NX-SL3500)	
	Append Slave 00	03 Module 3 (NX-SID800) 24 Module 4 (NX-ID5342)	
	Paste Slave	Systems	
	Edit lopology Expand All	·	
	Collapse All		
	Show Master Status Watch EtherCAT Mapped Variables		
	Network Mismatch Analyzer	nguage	
	Line Crossed Analyzer Configuration Mode		
	Diagnosis Mode		
	Enable Cable Redundancy	- û ×	
	Import PDD from Sysmac file	ile Properties 👻	
	Import SRA Parameter from Sysmac file	▲	
	Import Slaves from ENI Load Mapping to Power PMAC from ENI	Master0 (Deactivated)	
	Export ENI File		
0			
2.	Among the files that you exp	ported in <u>Export Procedure</u>	e for the Safety Configuration File,
	select SraParameterList.xm	<i>I</i> and click the <i>Open</i> Butto	on.
	Name Status	Date modified Type	Size
	CouplerCopyInfo.xml	10/12/2024 16:18 Microsoft Edge H	2 KB
	CouplerEsi E002.xml	10/12/2024 16:18 Microsoft Edge H	17 KB
	CouplerMemoryMap.xml	10/12/2024 16:18 Microsoft Edge H	1 KB
		10/12/2024 16:18 Microsoft Edge H	10 KB
	SraParameterlist xml	10/12/2024 16:18 Microsoft Edge H	1 KB
	ie: SraParameterList.xml	~ XML	Files (*.xml) V
			Open Cancel
	When the following dialog be	ox appears aligh the OK	Puttop
		ox appears, click the OA I	Button.
	Power PMAC	× Power PMAC	×
	This will updated the SRA Parameters for all match sla	wes, Do	nu undeted
	you still want to continue :		
	OK \$	F#>ZU	ОК
3.	Open Slave_1001 [R88D-13	SN01L-ECT-51] (1001) fro	om the Solution Explorer and
	display the Init Commands 1	Гаb Page.	
	Check that OD is added as	shown below	
	Device Editor		
	General Modules PDO Mapping Variables Advanced Options Distrib	buted Clock Init Commands CoE Object-Dictionary Sync Units	
	Init Commands		
	Transition Protocol Index Value Pre-Op-> Safe-Op CoE 0x1C12x000 0		Comment Access clear sm pdos (0x1C12) RO
	Pre-Op-> Safe-Op CoE 0x1C13:000 0		clear sm pdos (0x1C13) RO
	Pre-Op->Safe-Op CoE 0x1A00000 07 00 10 00 41 60 20 00 64 60 7	10 00 89 60 20 00 8A 60 20 00 8C 60 10 00 3F 60 20 00 FD 60	download pdo 0x1A00 entries RO
	Pre-Op-Safe-Op CoE 0x160000 03 00 10 04 06 20 00 7A 60	10 00 88 50	download pdo 0x1600 entries RO
	Pre-Op-> Safe-Op CoE 0x1610:000 13:00:08:01:00:E7:01:00:40:66 0	01 01 50 56 01 00 00 00 01 00 00 01 00 00 00 01 00 00	download pdo 0x1610 entries RO
	Pre-Op->Safe-Op CoE 0x1C12:000 02 00 04 17 10 16 Pre-Op->Safe-Op CoE 0x1C13:000 04 00 02 18 20 18 FF 18 10 14		download pdo 0x1C12 index RO download pdo 0x1C13 index RO
	Pre-Op->Safe-Op CoE 0x60601000 8		RW
	Pre-Op->Safe-Op CoE 0x2002002 1 Pre-Op->Safe-Op CoE 0x4504041 2		RW Import from Svenso file RW
	oper sale-op coe over cover c		



3.4.4. Setting Axis Variables

1.	Open global definitions.pmh under ProjectName - PMAC Script Language - Global						
	Includes from the Solution Explorer.						
	Solution Explorer						
	○ ○ ☆ [™] → -						
	Search Solution Explorer (Ctrl+:)						
	CK5M_StartupGuide_Sample01						
	▶ 🛑 System						
	Tools						
	Clanguage						
	Documentation						
	▶ 📕 Log						
	PMAC Script Language						
	ECATMap.pmb						
	🗋 global definitions.pmh						
	Kinematic Routines						
	Motion Programs						
	PLC Programs						
<u> </u>							
<u>.</u>	virite the following code in the program	ming area.					
	//define						
	#define true 1						
	#define false 0						
	<i>"</i>						
	// Motor						
	Motor[1].ServoCtrl=1	//enable motor control					
	Motor[1].Ctrl=Sys.PosCtrl	// Output command position to pdac					
	Motor[1].EncType=0	//Encoder type None					
	Motor[1].pDac=Slave_1001_R88D_1SN01L_ECT_51_1001_607A_0_Targetposition.a						
	Matarial n Enge EngTable [4] a	//Position command pointer					
	Motor[1].pEnc=EncTable[1].a	//Position reedback pointer					
	Motor[1].pAmpEnable=Slave_1001_R88D_1SN01L_ECT_51_1001_6040_0_Controlword.a						
	······································	//driver directive pointer					
	Motor[1].AmpEnableBit=3	//Reference bits in the driver directive pointer					
	Motor[1].pAmpFault=Slave_1001_R88D_1SN01L	_ECT_51_1001_6041_0_Statusword.a					
		//Pointer driver error					
	Motor[1].AmpFaultBit=3	//Reference bit of the driver fault pointe(Fault bit)					
	Motor[1].AmpFaultLevel=3	//Logical state of driver error.					
	Motor[1].EcatAmpFaultLimit=1000	//O. fterrore line it all a bland					
	Motor[1].pLimits=0	//Software limit disabled					
	Motor[1].LimitBits=0 Motor[1].WarnEel.imit=1000	//Number of limit signal bits for motors					
	Motor[1] FatalFel imit=0	//Deviation Abnormal Limit Value					
	Motor[1].Stime=ECAT[0].ServoExtension	//Extension of servo cycle					
	Motor[1].MaxSpeed=3000/60*(1<<23)/1000	//Maximum speed 23-bit encoder 3000 r/min					
	Motor[1].pAdc=Sys.pushm	·					
	Motor[1].pPhaseEnc=Sys.pushm						
	Motor[1].pEncStatus=Sys.pushm						
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm						
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm Motor[1].CaptControl=0						
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm Motor[1].CaptControl=0 Motor[1].pCaptFlag=Sys.pushm						
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm Motor[1].CaptControl=0 Motor[1].pCaptFlag=Sys.pushm Motor[1].pCaptPos=Sys.pushm						
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm Motor[1].CaptControl=0 Motor[1].pCaptFlag=Sys.pushm Motor[1].pCaptPos=Sys.pushm Motor[1].PosSf=1	//electronic gear ratio					
	Motor[1].pEncStatus=Sys.pushm Motor[1].pEncCtrl=Sys.pushm Motor[1].CaptControl=0 Motor[1].pCaptFlag=Sys.pushm Motor[1].pCaptPos=Sys.pushm Motor[1].PosSf=1 Motor[1].Pos2Sf=1	//electronic gear ratio //electronic gear ratio					

Motor[1].JogTa=500	//Jog acceleration/deceleration time
Motor[1].JogTs=500	//Jog S-curve acceleration/deceleration
Motor[1].Abort1a=100	//Deceleration during Abort
Motor[1].JogSpeed=1200/60"(1<<23)/1000	//Jog speed/ms 23-bit encoder 1200 r/min
Motor[1] InvAmax=10	//Home search speed/ms
Motor[1].hvDmax=10	//Maximum deceleration
Motor[1] Inv.Imax=50	//Max.lerk
Motor[1].MaxDac=32768	//Maximum DAC output
//Encoder	
Encrable[1].type=1 Encrable[1] index1=0	
EncTable[1] index $2=0$	
EncTable[1].index3=0	
EncTable[1].index4=0	
EncTable[1].index5=0	
EncTable[1].pEnc=Slave_1001_R88D_1SN01L	_ECT_51_1001_6064_0_Positionactualvalue.a
EncTable[1].pEnc1=Slave_1001_R88D_1SN01	L_ECT_51_1001_6064_0_Positionactualvalue.a
EncTable[1].ScaleFactor=1	
Note: Variables such as	
Slave_1001_R88D_1SN01L_ECT_51	_1001_6064_0_Positionactualvalue are the
parameter variables included in ECAT	Map.pmh that you created in 3.4.3 Configuring
EtherCAT Communications Settings	Check the variable names in advance, as they y
LineroAr Communications Settings.	Sheek the valiable hattles in advance, as they t
depending on the slave names specifi	ed in the Sysmac Studio project that you create
in 3.3 Setup of NX-series Safety Cont	rol Units or the Power PMAC IDE project that y
created in 3.4.3 Configuring EtherCAT	Communications Settings.

// Inputs // inputs
#define Slave_1001_R88D_1SN01L_ECT_51_1001_603F_0_Errorcode ECAT[0].I0[4096].Data
#define Slave_1001_R88D_1SN01L_ECT_51_1001_6041_0_Statusword ECAT[0].I0[4097].Data
#define Slave_1001_R88D_1SN01L_ECT_51_1001_6064_0_Positionactualvalue ECAT[0].I0[4098].Data
#define Slave_1001_R88D_1SN01L_ECT_51_1001_6077_0_Torqueactualvalue ECAT[0].I0[4099].Data
#define Slave_1001_R88D_1SN01L_ECT_51_1001_6061_0_Modesofoperationdisplay ECAT[0].I0[4100].Data

3.4.5. Creating an Operation Program

Open plc1.plc under ProjectName - PLC Programs - Global Includes from the Solution 1. Explorer. Solution Explorer ○ ○ ☆ 'o • ♂ ≯ -Search Solution Explorer (Ctrl+:) CK5M_StartupGuide_Sample01 📕 System Þ 📕 Tools ⊳ ⊳ 🛑 C Language 🛑 Configuration Þ 🛑 Documentation 🛑 Log ⊳ 📹 PMAC Script Language 🛑 Global Includes 🛑 Kinematic Routines 🛑 Libraries 📕 Motion Programs PLC Programs 🗋 pic1.pi 2. Write the following program in the programming area of the plc1.plc Tab Page. This program causes the motor shaft to run at 1,200 rpm three seconds after the Servo is turned ON after the reset switch is pressed. /*For more information see notes.txt in the Documentation folder */ global moveSequence = 0; //for plc1 Sequence //Check if the reset button is pressed global isResetButton = false; global STOCommand = true; //sto command(true:Deactivate) global STOStatus = false; //sto command(false:Deactivate) open plc 1 while(sys.ecatMasterReady==0){}; isResetButton = (Slave_1002_NX_ECC203_1002_6042_1_StandardInput1stWord >> 6) & 1; STOCommand = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_130_MirrorSafetycontrolword & 1); STOStatus = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_131_MirrorSafetystatusword & 1); switch(moveSequence) { case 0://Setting //EtherCAT Enabled ECAT[0].Enable=true; //Positive/Negative torque limit value set to 30% Slave_1001_R88D_1SN01L_ECT_51_1001_60E0_0_Positivetorquelimitvalue = 300; Slave_1001_R88D_1SN01L_ECT_51_1001_60E1_0_Negativetorquelimitvalue = 300; Ldata.motor = 1; moveSequence = 1; break;



3.4.6. Downloading the Project and Checking the Operation

Download the created project to the Controller.

After the project is downloaded, the program starts automatically.





3.5. Setup of the Servo Drive

Set up the Servo Drive using the Sysmac Studio.

If you are continuing the operation from <u>3.4 Setup of the Motion Controller CK5M</u>, set the connection status of the CK5M to *No Device* from *Communication Setup* in the Power PMAC IDE.

3.5.1. Connecting the Servo Drive via CK5M





3.5.2. Motor, ABS Encoder and I/O Setup



Quick Parameter Setup and I/O Monitor Wizard

4.	Only when using a Servomotor with an absolute encoder, select the Use as absolute encoder but ignore multi-rotation counter overflow option for How to Use Absolute Encoder. How to Use Absolute Encoder • Use as absolute encoder • Use as incremental encoder • Use as absolute encoder but ignore multi-rotation counter overflow Transfer To Drive NOTE: This setting changes 4510.01 hex 'Operation Selection when Using Absolute Encoder'.
5.	Set up the absolute encoder (if required). Setup Absolute Encoder Launch Motor and Encoder view Use this function when clearing the multiple rotation data or when replacing a Servomotor in the actual machine. To reset multiple rotation data, click the Clear system Button.
	Corr grate Corr grate Multiple rotation data will be cleared, and the machine system will change to a new position data system.
	You need to restart the Servo Drive to complete the operation. Click the Yes Button.

	Check that multiple rotation data of the encoder has been cleared.			
	▼ Monitor			
	, Name Name			
	Incoder Error Encoder - Encoder Communications Error C			
	▼ Encoder Status ✓ Encoder - Resolution per Rotation 8388608			
	Encoder - One-rotation Data 5818523 Encoder Unit Encoder - Multi-rotation Data 0 Rotations			
	Encoder - Electric Angle 168 degree			
	Incoder - Encoder Temperature 42 °C			
6.	Select the motor rotation direction and transfer the settings to the Servo Drive.			
	Motor Rotation -			
	CW (Clockwise) CCW (Counterclockwise)			
	Transfer To Drive			
	NOTE: This changes 3000.01 hex 'Motor Rotation Direction Setting'.			
7.	Set input signals and transfer the settings to the Servo Drive.			
	The Error Stop Input (ESTP) is ON by default. Turn it OFF as follows if necessary.			
	When ESTP is ON, the Error No. 87.00 is displayed on the Servo Drive.			
	Node2:R88D-ISN01Le. ×			
	Input Signals			
	condition signal status ^{Pin} No. IN1 None Fligh I 1 21			
	IN2 Positive Drive Prohibition Input - F ▼ Low EDM- Bigh S2 S7A			
	IN3 Negative Drive Prohibition Input V High 13 57+ O Low 572 V Low 572- V Low 72- V			
	IN4 Home Proximity Input - Port Select ▼ Unign 33 / ERR - OO (CHR - OUT) UN5 Monitor Input 1 - Port Selection (N ▼ U High 0 Hi			
	IN6 Monitor Input Z - Port Selection () V Low Low NA			
	IN7 External Latch Input 1 - Port Select T High 15 GRU B-			
	IN8 External Latch Input 2 - Port Select			
	Return to Factory Setting Transfer To Drive			
0	Back to Portal < Back Next>			
8. 0	Set output signals if necessary and transfer the settings to the Servo Drive.			
9.				
	< Back Finish			

3.6. Operation Check of the STO Function

1.	Execute the \$\$\$ command from the Terminal of the Power PMAC IDE to restart the	
	CK5M.	
	Terminal	
	\$\$\$ Resetting Power PMAC	
	Power PMAC Reset complete Disconnected from Power PMAC at 192.168.0.200	
	SSH communication to Power PMAC at 192.168.0.200 successful etst	
	Resetting Power PMAC	
	\$\$\$	
	Power PMAC Messages Terminal Output	
2.	After the restart of the Controller is completed, press the safety reset button.	
3.	Check that the 7-segment LED display shows 'oE.'.	
•		
4.	After about three seconds, check that the Servomotor rotates at about 1,200 r/min.	
5.	Press the Emergency Stop Pushbutton Switch.	
	Check that the 7-segment LED display shows 'st'.	
6.	Release the Emergency Stop Pushbutton Switch and press the safety rest button.	
	Check that the STO is released and that the 7-segment LED display initially shows ""	
	and then immediately changes to 'oE.'.	
	$\overline{a}E.$	
	Note: If the LED display does not change to 'oE.', press the safety reset button again.	
4. Adding Safety Functions

This section describes how to add safety functions to the servo system that you built in <u>3. Performing</u> <u>Setup</u>.

Refer to the section of the safety function to add.

4.1. Adding the Safe Stop 1 (SS1) Function

This section describes how to add the SS1 function to the project that you created in <u>3. Performing</u>. <u>Setup</u>.

The operation of the servo system set up in this section is explained below.

- 1. When the error clear button is pressed, the errors of the standard controller and Servo Drive are reset.
- When the Safety Key Selector Switch is operated to switch to safety active mode, the standard controller lets the Servomotor decelerate to a stop. The Servo Drive activates the STO function using the SS1 function to turn OFF the motor torque. When the Emergency Stop Pushbutton Switch is pressed, the motor torque is turned OFF.
- 3. When the safety reset button is pressed, the STO status is reset.



Input device	State	Operation
1. Error clear button	ON	Enable error reset command
	OFF	Disable error reset command
2. Safety Key	Normal	Set the Servomotor to normal velocity.
Selector Switch	operating	
	mode	
	Safety	Make Servomotor decelerate to a stop and activate STO
	active mode	function using SS1 function.
3. Safety-door Switch	Open	SS1 function deactivated: Enable STO command
		SS1 function activated (during deceleration):
		Enable STO command
		SS1 function activated (after STO activation from SS1):
		Disable STO command
	Close	Disable STO command
4. Emergency Stop	ON	Enable STO command
Pushbutton Switch	OFF	Disable STO command
5. Safety reset button	ON	Enable reset STO status command
	OFF	Disable reset STO status command

■ Operation of SS1 Function Interlocked with Motion Control

- 1. When the Servo ON command is enabled, the Servo Drive turns ON the Servo.
- 2. When an operation command is enabled, the command velocity to the Servomotor is 1,200 r/min.
- The standard controller lets the Servomotor decelerate to a stop.
 When the SS1 function is executed, the Servo Drive shifts to the STO state after the wait time (SS1 time to STO 1) and turns OFF torque.



4.1.1. Setting the Safety Controller

1.	Click new_SafetyCPU0.			
	Multiview Explorer			
2.	Open the Safety Function Assigr	nment Se	ttings view for SRA	Parameters.
	Multiview Explorer	is0 : Instance0)	SS1	
3.	Check the Active Check Box for	function I	No.1 and assign SS	1 instance1 to
	function No.8.			
	Next, click the SS1 Button to c You can also use the	lisplay the Button 1 Settings	e SS1 Detailed Setti to display the SS1 D Sto Sto Sto Sto Sto Stoommand Sto Stoommand Sto Reserved Reserved Reserved Res	ngs view. etailed Settings view. Status D Active erved
5.	Set SS1 parameters.			
	In this Guide, set as follows:			
	Name		Value	Unit
	SS1 time to STO 1	1,500		ms
	 Section 0 - Program 0 VIO Map SRA Parameters × SS1 SS1 SS1 SS1 SS1 Manual 			
	SS1 ✓ Instance Settings OD	1500	Value I Unit I	Reference Information
	SLS			









4.1.2. Setup of the CK5M

1.	Execute Scan EtherCAT Network to scan the current configuration.
	CK5M_StartupGuide_SS1_Sample
	A 🛁 System
	F Hardware
	🔺 🛁 EtherCAT
	Master0
	2 1 Slave_1001 (R88D-1SN01L-ECT-51) (1001)
	▲ II Slave_1002 [NX-ECC203] (1002)
	001 Module 1 (NX-PF0630)
	002 Module 2 (NX-SL3500) 003 Module 3 (NX-SL0800)
	004 Module 4 (NX-ID5342)
	Motors
	Coordinate Systems
	Note: Refer to Configuring EtherCAT Master Communications in section 3.4.3 for
	details on the procedure.
2	Open the Distributed Clocks Tab Page for Master() (Deactivated) and select the Bus
	Shift (Reference Clock controlled by EtherCAT Master Time) ontion for Clock
	Adjustment.
	Master0 (Deactivated) → × Slave 1001 [R88D-1SN01L-ECT-51] (1001)
	Device Editor
	Master Topology View Process Data Image Variables Advanced Options Slave to Slave Distributed Clocks Tasks + Sync Units
	Reference Clock
	Name Slave_1001 [R88D-1SN01L-ECT-51] (1001)
	Clock Adjustment Master Shift (EtherCAT Master Time controlled by Reference Clock) or
	Link Layer (Reference Clock controlled by Link Layer)
	Bus Shift (Reference Clock controlled by EtherCAT Master Time)
	External Mode (Reference Clock controlled by External Sync Device)
	▼
	Note: Refer to <u>Configuring Distributed Clock Settings in section 3.4.3</u> for details on the
	procedure.
3.	Open Slave_1001 [R88D-1SN01L-ECT-51] (1001) and Slave_1002 [NX-
	<i>ECC203](1002)</i> from the Solution Explorer and display the Distributed Clock Tab Page.
	Set Operation Mode to DC for synchronization.
	Slave_1001 (R88D-1SN01L-ECT-51) (1001) * X Master0 (Deactivated) Slave_1011 (R88D-1SN01L-ECT-51) (1001) * X Master0 (Deactivated) Solution Explorer X
	General Modules PDO Mapping Variables Advanced Option: Distributed Clock init Commands CoE Object-Dictionary Sync Units Search Solution Explorer (Ctrl+:)
	Distributed Clock Deration Mode DC for synchronization
	Sync Unit Cycle (us) 1000 System
	Sync Units
	✓ Sync Unit 0 Slave, 1001 (R88D-15N01L-ECT-51) (1001)
	Sync Unit Cycle Sync Unit Cycle Sync Unit Cycle 1000 us
	User denied 1000 001 002 003 Module 3 (NV-SDS00) Shift Time (us) 004
	Sync Unit 1 Motors Coordinate Systems
	Sync Unit Cycle Dus Dus
	Sync u Cycle x1 • U us User defined
	Shift Time (us)

Δ	Decompress the zin file ex	ported from the Sv	smac Studio (see 4.1.1 Setting the Safety		
т.	Controller), import <i>SlaveMemoryMap.xml</i> from the folder, and configure the PDO to				
	open it.				
	Scan EtherCAT Network Load Mapping to Power PMAC Activate EtherCAT Reset EtherCAT Reset EtherCAT Append Slave Paste Slave Edit Topology Expand All	Explorer Solution Explorer (Ctrl+.) System CPU Hardware EtherCAT Size_1002 [NK-EC233] (1002) O01 Module 1 (ES6-54.5) Size_1002 [NK-EC233] (1002) O01 Module 2 (NK-E080) O03 Module 2 (NK-S13500) O03 Module 2 (NK-S13500) O04 Module 4 (NK-ID5342) Motors Coordinate Systems	• • • •		
	Collapse All Show Master Status Watch EtherCAT Mapped Variables Network Mismatch Analyzer Line Crossed Analyzer Configuration Mode	Encoder Tools Conguage Configuration Documentation Log PMAC Script Language			
	Congeneration Mode Diagnosis Mode EGE Endpoint Configuration for Import SPO from Sysmac file Import Slaves from ENI Na	ties 0 File Properties 6 P Name Master0 me			
	Load Mapping to Power PMAC from ENI Export ENI File	me of the file or folder			
	Note: Refer to Configuring F	PDO Map Settings in	n section 3.4.3 for details on the procedure.		
5.	Import CouplerMemoryMap the safety controller. y 0x1701) 0x1704	<i>p.xml</i> from the folde	er decompressed in step 4, and set up		
	y 0x1701) 0x1705	5	001 Module 1 (NX-PF0630)		
	Import Sysmac Studio Safety mapp	ing file	003 Module 3 (NX-SL5500) 003 Module 3 (NX-SL5800)		
	C Open		004 Module 4 (NX-ID5342)		
	Scope to This New Solution Explorer View		te Systems		
	Properties	Alt+Enter			
	Note: Refer to Setting the S	Safety Controller in s	section 3.4.3 for details on the procedure.		
6.	Import SraParameterList.x	<i>ml</i> from the folder o	lecompressed in step 4, and set the SRA		
	parameters.				
	Comment Access A	re			
	clear sm pdos (0x1C13) RO	.T ter0 (Deactivated)			
	Scan EtherCAT Network Load Mapping to Power PMAC	ve_1001 [R88D-1SN01L-ECT-51] (1001) ve_1002 [NX-ECC203] (1002)			
	Activate EtherCAT Reset EtherCAT	001 Module 1 (NX-PF0630) 002 Module 2 (NX-SL3500)			
	Append Slave	003 Module 3 (NX-SID800) 004 Module 4 (NX-ID5342)			
	Paste Slave Edit Topology	ie Systems			
	Expand All				
	Show Master Status	- 1			
	Watch EtherCAT Mapped Variables Network Mismatch Analyzer	on			
	Line Crossed Analyzer	Language			
	Configuration Mode Diagnosis Mode				
	Enable Cable Redundancy	- 	×		
	EoE Endpoint Configuration Import PDO from Sysmac file) File Properties	•		
	Import SRA Parameter from Sysmac file		*		
	Import Slaves from ENI Load Mapping to Power PMAC from ENI	Master0 (Deactivated)	*		
	Export ENI File	-			
	Note: Refer to Setting the S	RA Parameters in s	section 3.4.3 for details on the procedure.		

7.	Create an EtherCAT network configuration file.
0	Solution Explorer Image: Solution Explorer (Ctrl+:) Search Solution Explorer (Ctrl+:) Search Solution Explorer (Ctrl+:) CK5M_StartupGuide_Sample02 System Image: System Image: System Image: Search Solution Explorer (Ctrl+:) Image: System Image: System Image: System
б.	Follow the same procedure as in section <u>3.4.4 Setting Axis Variables</u> to set axis
9.	Modify the operation program. Add the following codes to <i>plc1.plc</i> . The codes shown in the red frame below are added or modified from the program that you created in <u>3.4.5 Creating an Operation Program</u> .
	/*For more information see notes.txt in the Documentation folder */ global moveSequence = 0; //for plc1 Sequence global isResetButton = false; //Check if the reset button is pressed global STOCommand = true; //sto command(true:Deactivate) global STOStatus = false; //sto command(false:Deactivate) global SS1Status = false; //ss1 command(false:Deactivate) global SS1Status = false; //ss1 command(false:Deactivate)
	<pre>while(sys.ecatMasterReady==0){}; isResetButton = (Slave_1002_NX_ECC203_1002_6042_1_StandardInput1stWord >> 6) & 1; STOCommand = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_130_MirrorSafetycontrolword & 1); STOStatus = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_131_MirrorSafetystatusword & 1); SS1Status = ((Slave_1001_R88D_1SN01L_ECT_51_1001_4130_131_MirrorSafetystatusword>>8)&1); switch(moveSequence) { case 0://Setting //EtherCAT Enabled ECAT[0].Enable=true; //Positive/Negative torque limit value set to 30% Slave_1001_R88D_1SN01L_ECT_51_1001_60E0_0_Positivetorquelimitvalue = 300;</pre>
	Slave_1001_R88D_1SN01L_ECT_51_1001_60E1_0_Negativetorquelimitvalue = 300; Ldata.motor = 1; moveSequence = 1; break; case 1://Check if the reset button is pressed. if(isResetButton == 1) { moveSequence = 2; } break;



Check that the Safety Key Selector Switch is in normal operating mode. 1. RUN SAFETYACTIVE 0 2. Execute the \$\$\$ command from the Terminal of the Power PMAC IDE to restart the CK5M. Terminal \$\$\$ Resetting Power PMAC ower PMAC Reset complete Disconnected from Power PMAC at 192.168.0.200 SSH communication to Power PMAC at 192.168.0.200 successful \$\$\$ Resetting Power PMAC ower PMAC Reset complete Power PMAC Messages Terminal Output After the restart of the Controller is completed, press the safety reset button. 3. 4. Check that the 7-segment LED display shows 'oE.'. After about three seconds, check that the Servomotor rotates at about 1,200 r/min. 5. 6. Operate the Safety Key Selector Switch to switch to safety active mode. SAFETYACTIVE RUN The Servomotor decelerates to a stop and the Servo Drive goes into STO state. Check that the 7-segment LED display shows 'st'.

4.1.3. Checking Operation of the SS1 Function

This section describes how to add the SLS function to the project that you created in <u>3. Performing</u> <u>Setup</u>.

The operation of the servo system set up in this section is explained below.

- 1. When the error clear button is pressed, the errors of the standard controller and Servo Drive are reset.
- 2. When the Safety Key Selector Switch is operated to switch to safety active mode, the standard controller changes the velocity command value to low speed. The Servo Drive activates the SLS function and monitors the motor velocity.
- 3. When the guard with the Safety-door Switch is opened while the SLS function is inactive, the motor torque is turned OFF.
- 4. When the Emergency Stop Pushbutton Switch is pressed, the motor torque is turned OFF.
- 5. When the safety reset button is pressed, the STO status is reset.



System Configuration

Input device	State	Operation
1. Error clear	ON	Enable error reset command
button	OFF	Disable error reset command
2. Safety Key	Normal	Run Servomotor at 1200 [r/min] and deactivate SLS
Selector Switch	operating	function.
	mode	
	Safety	Run Servomotor at 300 [r/min] and activate SLS function.
	active mode	When velocity exceeds SLS velocity limit, Servo Drive goes
		into STO state and SLS Excessive Limit Value Error occurs.
3. Safety-door	Open	SLS function deactivated: Enable STO command
Switch		SLS function activated: Disable STO command
	Close	Disable STO command
4. Emergency Stop	ON	Enable STO command
Pushbutton	OFF	Disable STO command
Switch		
5. Safety reset	ON	Enable reset STO status command
button	OFF	Disable reset STO status command

■ Operation of SLS Function with Motion Control

- 1. When the Servo ON command is enabled, the Servo Drive turns ON the Servo.
- 2. When an operation command is enabled, the command velocity to the Servomotor is 1,200 r/min.
- 3. When the SLS function is executed, the Servo Drive shifts to the SLS state after the wait time (SLS time to velocity monitoring 1) and monitors the motor velocity. The standard controller sets the command velocity to the Servomotor to 300 r/min.
- 4. When the SLS function is released, the Servo Drive goes into the normal state and stops monitoring the motor velocity.

The standard controller sets the command velocity to the Servomotor to 1,200 r/min.





Precautions for Correct Use

 When using the SLS function, depending on the operation conditions or operating environment in which it is used, an error may occur during normal operation.
 For further details, refer to 8-4 Safely-limited Speed (SLS) Function in the 1S-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications and SS1/SLS Safety Sub-Functions User's Manual (Cat. No. 1696).

4.2.1. Setting the Safety Controller



5.	Set SLS parameters.					
	In this Guide, set as follows:					
	Name	Value	U	nit		
	SLS time to velocity monitoring 1	2,000	n	ns		
	SLS velocity limit 1	500	r/r	min		
	Error Detection Activate In SLS Deactivate	Activate	-			
	SRA Parameters × SLS SLS SLS SLS SS1 V OD V 6691.01 SLS instance SLS SLS instance V Instance Settings OD V 6693.01 SLS Subjective finit 1 4F16.01 Error Detection Activative Timing Chart SLS command	S Manual ame onitoring 1 200 500 te In SLS Deactivate (SL 11	Valı 0 Activate	ue V	Unit I Referen Ims I r/min -	ice Information 1
6.	Open the I/O Map and creat	e device varia	bles b	y right-c	licking the po	rt to set and
	clicking Create Device Varia	<i>ble</i> from the r	nenu.			
	Port				Variable na	ame
	SLS command1 Active for ECT-51	R88D-1SN01	L-	E001_9	SLS_comman	d1_Active
	SLS command1 for R88D-	1SN01L-ECT-	·51	E001_9	SLS_comman	d1
		L-ECT-51	EBOOL E001_ST EBOOL E001 E01 EBOOL E001 E01 EBOOL E001_SL EBOOL E001_SL EBOOL E001_SL EBOOL E001_ST EBOOL E001_ST EBOOL E001_ST EBOOL E001_SL EBOOL E001_SL	10_Active Top IS_command1_Active fety_Connection_Statu TO mr_Ack S_command1	Image: Section of the sectio	Global Variables Global Variables Global Variables Global Variables Global Variables Global Variables Global Variables Global Variables





9.	Download the safety application.
	Select <i>new_SafetyCPU0</i> from the list.
	new_Controller_0 new_SafetyCPU0 KeherCA1 Main Base - 15N02L-ECT (E001
	Click the PROGRAM Mode Button to switch to PROGRAM mode.
	Click the DEBUG Mode Button to enter DEBUG mode.
	DEBUG Mode
	Click the DEBUG Mode Button to start DEBUG mode.
	Start Debugging
	Click the Safety Validation Button.
	E E C C
	The safety application is now ready to run.
	Safety Validation
	Safety CPU Unit will start in RUN mode on next startup
	Click the RUN Mode Button.
	🔥 🔺 68 🖗 🕞 🗣 📬 🖗 🌾 🎬 RUN Mode



4.2.2. Setup of the CK5M





7.	Create an EtherCAT network configuration file.				
	Solution Explorer Image: Construction Explorer (Ctrl+:) Search Solution Explorer (Ctrl+:) Image: CPU <				
	details on the procedure.				
8.	Set up the Servomotor.				
	Set it in the same way as in <u>3.4.4 Setting the Axis Variables</u> .				
9.	Modify the operation program. Add the following codes to <i>plc1.plc</i> .				
	The codes shown in the red frame below are added or modified from the program that				
	you created in <u>3.4.5 Creating an Operation Program</u> .				
	/*For more information see notes.txt in the Documentation folder */				
	global moveSequence = 0: //for plc1 Sequence				
	global SLSSequence = 0; //SLS Sequence				
	global isResetButton = false; //Check if the reset button is pressed				
	global STOCommand = true; //sto command(true:Deactivate)				
	global STOStatus = false; //sto command(false:Deactivate)				
	global SLSStatus = false; //ss1 command(false:Deactivate)				
	open plc 1				
	while(sys.ecatMasterReady==0){}; isResetButton = (Slave_1002_NX_ECC203_1002_6042_1_StandardInput1stWord >> 6) & 1; STOCommand = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_130_MirrorSafetycontrolword & 1); SLSCommand = ((Slave_1001_R88D_1SN01L_ECT_51_1001_4130_130_MirrorSafetycontrolword>>8)&1); STOStatus = (Slave_1001_R88D_1SN01L_ECT_51_1001_4130_131_MirrorSafetystatusword & 1); SLSStatus = ((Slave_1001_R88D_1SN01L_ECT_51_1001_4130_131_MirrorSafetystatusword>>8)&1);				
	switch(moveSequence)				
	<pre>case 0://Setting //EtherCAT Enabled ECAT[0].Enable=true; //Positive/Negative torque limit value set to 30% Slave_1001_R88D_1SN01L_ECT_51_1001_60E0_0_Positivetorquelimitvalue = 300; Slave_1001_R88D_1SN01L_ECT_51_1001_60E1_0_Negativetorquelimitvalue = 300; Ldata.motor = 1; moveSequence = 1; break;</pre>				
	<pre>case 1://Check if the reset button is pressed. if(isResetButton == 1) { moveSequence = 2; } }</pre>				
	break;				



Check that the Safety Key Selector Switch is in normal operating mode. 1. SAFETYACTIVE RUN 0 2. Execute the \$\$\$ command from the Terminal of the Power PMAC IDE to restart the CK5M. Terminal \$\$\$ Resetting Power PMAC ower PMAC Reset complete Disconnected from Power PMAC at 192.168.0.200 SSH communication to Power PMAC at 192.168.0.200 successful \$\$\$ Resetting Power PMAC ower PMAC Reset complete \$\$\$ Power PMAC Messages Terminal Output 3. After the restart of the Controller is completed, press the safety reset button. 4. Check that the 7-segment LED display shows 'oE.'. After about three seconds, check that the Servomotor rotates at about 1,200 r/min. 5. 6. Operate the Safety Key Selector Switch to switch to safety active mode. SAFETYACTIVE RUN Check that the Servomotor rotates at about 300 r/min. Check that the 7-segment LED display shows 'SF'.

4.2.3. Checking Operation of the SLS Functions



Appendices

Test Run and Data Trace, Easy Tuning, Manual Tuning, and Advanced Auto-Tuning in Appendices are all performed using the Sysmac Studio.

Before you proceed, refer to <u>3.5.1 Connecting the Servo Drive via CK5M</u> and connect the Sysmac Studio to the Servo Drive.

Note: Please add the following code to *plc1.plc*, which is included in the CK5M. The project that you created in <u>3.4</u> or <u>section 4</u> cannot be used for trial run because it is designed to run the Servomotor automatically from servo ON.



Test Run and Data Trace



3.	Click the Servo ON Button to turn ON the Servo.
	Test Run Servo ON Drive Status Actual Current Position 426708262 pulse Actual Current Speed 0 rpm Jogging Step Target Speed 1000 rpm Acceleration/Deceleration Time 50 ms
4.	Right-click <i>Data Trace Settings</i> and select <i>Add - Data Trace</i> from the menu to add a new
	data trace.
	Multiview Explorer
5.	Select <i>Cyclic</i> for the trace type.
	Trace Type Single ▼ Sar Post-trigge Single 90 % Cyclic 164
6.	Specify the sampling interval.
	Sampling Interval Time Interval 500 us
7.	Specify the enable trigger condition.
	Enable Trigger Condition Trigger 1 Trigger 1 Position Command - Motor Velocity (16 bit) Trigger 2
8.	Click the <i>Execute</i> Button.



Easy Tuning









Manual Tuning

How to Perform Manual Tuning

This section describes how to change machine rigidity parameters for gain adjustment.

1.	Right-click the Servo Drive and select Setup and Tuning from the menu.
	Multiview Eplorer Multiview Epl
2.	Click the <i>Manual Tuning</i> Button.
	Setup and Tuning Portal
	You can do Quick Parameter Setup, I/O Monitoring and Tuning easily.
	▼ Quick Parameter Setup and I/O Monitor
	Quick Parameter Setup and I/O Monitor
	Setup basic parameters quickly and monitor I/O signals.
	▼ Tuning (Single Drive)
	Choose the type of tuning to perform:
	Easy Tuning Advanced Auto-Tuning Manual Tuning
	Tune based on simple steps Auto-/Manual tuning based on FFT stability Tune based on setting the machine civility.
	analysis results.
	The Menuel Tuning Window is displayed
	I the Manual Tuning Window is displayed.
	Node2 (1880-19/01/L-w_ × Main's Setting ① Saidt Set Set Set Set Set Set Set Set Set Se
	Prametes 2
	Image: Topological control of the second contrel of the second control of the second contrel of the second co
	E 201081 Postion Command - Postion Demand Value 0 0 0 Comma E 201082 Postion Command - Postion Demand Value 0 0 0 Encoder
	Image: Strate Command - Work Velocity 0 0 Command - Motor Velocity 0 Image: Strate Command - Motor Velocity 0 0 r/min - Image: Strate Command - Motor Velocity After Protin 0 0 r/min -
	Image: State Command - Motor Velocity After Damp. 0 0
	= 3011.04 Position Command Filter - IIIR Filter Cutoff Frequ 465.0 21.9 1.0 to 5000.0 Hz A = 30008.2 Velocity Command - Matry Velocity 0 0 0 r/min - = 3003.2 Velocity Command - Matry Velocity Alter Velocit 0 0 r/min -
	Hep
	Comment: Sets the rate of load inertia to motor rotor menta. Inertia ratio = (Load inertia + Rotor inertia) × 100%
	Actual Current Notition 2003/72037 Actual Current Notition Actual Current Noted
	i prime i prim
	Seno ON
	Show Block Diagrams TEP Position Control T Tender to Drive

3.	In order to check the behavior of the Servomotor, right-click Data Trace Settings and select
	Add - Data Trace from the menu to add a new data trace.
	Multiview Explorer
4.	Select <i>Cyclic</i> .
	Trace Type Single Sar Post-trigge Single 90 % Cyclic 164
5.	Adjust the sampling interval.
	Sampling Interval Time Interval 500 us
6.	Adjust the enable trigger condition.
	Enable Trigger Condition Trigger 1 V Trigger 1 Position Command - Motor Velocity (16 bit) Velocity (16 bit) r/min No Filter Trigger 2 No Filter
7.	Click the Transfer Parameters from Drive after Trace Button to disable uploading
	parameters.
	Image: 1 Kaster - ISAND For Mode2 / Kaster - ISAND For Mod
	Click the <i>Execute</i> Button.
	The Sysmac Studio waits for the trigger.
	El Output K Build Waiting for trigger
8.	Align the Test Run Window and the Manual Tuning Window horizontally by docking them.
	Image: State of the state
	I Device Name I Units ICursort/Minimum/AverageIX OffsetIY OffsetIY OffsetIY I E002 Velocity Detection - Present r/min 0 0 E002 Position Command - Motor V min 0 0 0 E002 Torque demand (16 bit) % 0 0 0 E002 Position Command - Followir Comma 1 Unit 0 0 0 0 Comma 1 Unit 0
	0.85
	0.55-0.55-0.5 0.55-0.5 0.55-0.5 0.55-0.45-0.45-0.45-0.45-0.45-0.45-0.45-
	Node: Idea: Idea: <td< th=""></td<>
-----	---
9.	Configure the motion profile and click the Apply Button.
10.	Click the Servo ON Button to turn ON the Servo and then click the Start Button.

11.	Data trace is now triggered, and trace results are displayed.
	금 Output 🔨 Build 금 Output 🔨 Build
	Sampling Transferring
	Each time the Servomotor moves, traced data will appear cyclically.
	Tace type langer with Ratio Part and Part of the Part
	I Device Name I Manne Lotts Currorr/Minimum/Maximum/MaxengetSX Offset1Y Offset1Y E 602 Postice Command - Motion 1 566 219.81 0 </th
	C 5002 Torque demand (16 ba) % 10.1 2.2 6.7 2.4765 0 0 1 10.1032 Petetion Command · Model Websity Support Su
	Constant Command - Motor Velocity After Damps Constant Constant Command - Motor Velocity After Damps Constant Constant Constant Command - Motor Velocity After Damps Constant Constan
	1 200 2 Velecity Command - Motor Velecity After Velec. 0 2
	0000 1
12.	It is possible to change gain values at once by changing the machine rigidity settings.
	Machine Settings 2 Rigidity 24 🔶 Responsiveness 🛛 🔿 Focus on tracking 🌑 Focus on overshoot suppression
	- Parameters 🔯
	Image: Solution Visit Visit Image: Solution Machine - Inertia Ratio 782 Image: Solution Machine - Inertia Ratio 782
	Sollos1 Position Command - Position Demand Value 2086049042 Sollos2 Position Command - Position Demand Internal V 2086049042 Sollos2 Position Command - Velocity O
	3010.84 Position Command - Motor Velocity 0 3010.85 Position Command - Motor Velocity After Positi 0 3010.85 Position Command - Motor Velocity After Positi 0
	Image: Solution Command - Following For 0 Image: Solution Command - Following For 0 Image: Solution Command Filter - IIR Filter Enable 0 : Disabled
	= 3011.04 Position Command Filter - III R Filter Cutoff Frequ 465.0 = 3020.82 Velocity Command - Motor Velocity 0 = 3020.83 Velocity Command - Motor Velocity After Veloci 0
	Comment: Sets the ratio of load inertia to motor rotor inertia. Inertia ratio = (Load inertia + Rotor inertia) x 100%
	Update drive settings with estimated values before transfer to drive. 2 Show Block Diagrams TDF Position Control T Transfer to Drive
	Click the Transfer to Drive Button to transfer the gain parameters to the Servo Drive.
13.	Repeat step 10, 11, and 12 until the desired performance is achieved.
	If vibrations occur, reduce the rigidity settings.
	Auto-Tuning and adjusting gains. Refer to <u>Advanced Auto-Tuning</u> in Appendices.

Advanced Auto-Tuning

This function uses FFT measurement data-based simulation to adjust the gain and filter settings automatically. Repeating actual Servomotor operation is not necessary, and a fine adjustment is possible in a short period of time.



How to Perform Advanced Auto-Tuning









Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V. Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD. 438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-3011 **OMRON ELECTRONICS LLC** 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388 Authorized Distributor:

©OMRON Corporation 2025 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. 1929-E1-01 0225 (0225)